

YAMAHA

SERVICE MANUAL

www.legends-yamaha-enduros.com



FOREWORD

This new YAMAHA HS1 motor cycle is the fully equipped 90-cc, parallel-twin engine sports model of the day.

The crowning feature that makes the 90HS1 the most advanced motor cycle is the adoption of 5-port cylinders to its engine. The addition of the auxiliary transfer ports has proved to be of great improvement in scavenging efficiency.

This unique design of the cylinder results in high performance of the engine, especially when combined with the ideal lubrication system-YAMAHA Autolube.

Among other features is the well-proportioned 5-speed transmission, which is most essential for sports cycles.

These outstanding features have not only made the HS1 comparable to a 125-cc motor cycle in performance, but succeeded in making lightly.

This manual is published to provide the information and guidance required for all YAMAHA service engineers who are charged with the task of maintaining YAMAHA HS1 models in top condition. It is sincerely hoped, therefore, that all YAMAHA service men will find it most useful in carrying out their work.

LEFT SIDE PROFILE OF HSI



RIGHT SIDE PROFILE OF HS1



CONTENTS

CHAPTER 1. GENERAL

1-1. Features	6
1-2. Specifications	7
1-3. Performance Curves	9
1-4. Service Tools	10

CHAPTER 2. YAMAHA AUTOLUBE

2-1. What is YAMAHA Autolube?	12
2-2. Features of YAMAHA Autolube	12
2-3. Handling the Oil Pump	13

CHAPTER 3. 5-PORT CYLINDERS

3-1. Description of 5-Port Cylinder	15
3-2. Construction and Features	15

CHAPTER 4. ENGINE

4-1. Removing the Engine	17
4-2. Cylinder Heads	21
4-3. Cylinders	22
4-4. Piston Pins	24
4-5. Piston Rings	25
4-6. Pistons	28
4-7. Crankcase Cover (R)	30
4-8. Tachometer Drive Gear Assembly	31
4-9. Clutch	32
4-10. Primary Drive Gear	38
4-11. Distance Collar	38
4-12. Kick Starter	39
4-13. Drive Sprocket	41
4-14. Shifting Mechanism	44
4-15. Splitting the Crankcase	46
4-16. Transmission Ass'y	47
4-17. Crankshaft	49

4-18. Bearings and Oil Seals	57
4-19. Carburetors	59
4-20. Air Cleaners	63

CHAPTER 5. CHASSIS

5-1. Front Wheel	64
5-2. Rear Wheel	69
5-3. Replacing Tires	71
5-4. Rear Sprocket Wheel	72
5-5. Rear Arm	73
5-6. Fuel Tank	73
5-7. Front Fork	74
5-8. Rear Cushion	76

CHAPTER 6. ELECTRICAL EQUIPMENT

6-1. General	77
6-2. Main Component Parts	77
6-3. Caution on Handling Electrical Equipment	85
6-4. Connection Diagram	87

CHAPTER 1. GENERAL

1-1 Features

1. Autolube

The Autolube Injection System, pioneered by Yamaha, assures extra reliability and durability for the engine. With Autolube the necessity for mixing oil and gasoline, as in other 2-stroke machines, is no longer necessary.

2. Five-Port Cylinders

The HS1 is a 90cc parallel twin incorporating five-port cast iron cylinders. Five-port design, pioneered by Yamaha, has resulted in faster acceleration and more reliable performance due to more efficient breathing characteristics within the combustion chamber of the engine.

3. Well-proportional 5-speed transmission

The well-proportional 5-speed transmission permits satisfactory gear shifting at anytime and anywhere on streets, hilly land or highway.

4. Primary Kick Starter

A primary kick starter permits the rider to start his machine without shifting gears to neutral. This is a most welcome convenience to the rider who happens to stall his machine, for example, in the midst of heavy traffic.

5. Starter Jets

The built-in mixture enrichening jet, the Starter Jet, which is design feature on all Yamaha carburetors, permits quick starts even in the coldest weather.

6. Powerful Brake

Patented waterproof, dustproof brake drum provide safe, fade-free braking on wet or road.

1-2 Specifications & Performance

The following data subject to change without notice.

Model	H S 1
Dimensions:	
Overall length	1 800 mm (70.9 in.)
Overall width	770 mm (30.3 in.)
Overall height	1,005 mm (39.6 in.)
Wheelbase	1,195 mm (47.0 in.)
Min. ground clearance	155 mm (6.1 in.)
Weight:	
Net	89 kg (196 lbs.)
Gross	99 kg (218 lbs.)
Performance:	
Max. speed	85 km/h plus (53 m/h plus)
Fuel consumption (on paved level road)	65 km/liter at 40 km/h (153 mile/g at 25 mph)
Climbing capacity	20 degrees
Min. turning radius	1,800 mm (70.9 in.)
Braking distance	6.4 m at 35 km/h (21.3 ft/(22 mph)
Engine:	
Type	HS1, 2 stroke, air cooled.
Cylinder	Two in parallel, forward inclined, 5 port.
Lubrication system	Separate lubrication (Yamaha Autolube)
Displacement	89 cc (5.43 cu. in.)
Bore × Stroke	36.5 × 43.0 mm (1.437 × 1.693 in)
Compression ratio	7.5 : 1
Max. output	4.9 HP/8,000 rpm
Max. torque	0.43 kg-m/5,500 rpm (3.1 ft. lbs/5.500 rpm)
Starting system	Primary kick
Ignition system	Battery ignition
Carburetor:	VM16SC × 2
Air cleaner:	Dry, paper filter
Transmission:	
Clutch	Wet, multi-disc
Primary reduction system	Helical gear
Primary reduction ratio	3.894 (74/19)

Gear box:

Type	Constant mesh, 5 speed forward
Reduction ratio 1st	3.182 (35/11), Total reduction ratio-38.126
Reduction ratio 2nd	1.813 (29/16), Total reduction ratio-21.723
Reduction ratio 3rd	1.300 (26/20), Total reduction ratio-15.576
Reduction ratio 4th	1.045 (23/22), Total reduction ratio-12.521
Reduction ratio 5th	0.840 (21/25), Total reduction ratio-10.064
Secondary reduction system	Chain
Secondary reduction ratio	3.077 (40/13)

Chassis:

Type of frame	Steel tubing, diamond structure
Suspension system, front	Telescopic fork
Suspension system, rear	Swing arm
Cushion system, front	Coil spring, oil damper
Cushion system, rear	Coil spring, oil damper

Steering system:

Caster	63.0 degrees
Trail	86.5 mm (3.4 in.)

Braking system:

Type	Internalexpansion
Operation method, front	Right hand operation, cable actuated.
Operation method, rear	Right foot operation, rod actuated.

Tire size:

Front tire	2.50-18-4PR
Rear tire	2.50-18-4PR

Tank capacity:

Fuel tank capacity	7.5 liters (2.0 US gals.)
Oil tank capacity	1.5 liters (1.6 US qt)

Generator:

Model	K108-09
Manufacturer	Hitachi

Spark plug:

B-9HC

Battery:

Model	12N5.5-3B
Capacity	12V5.5AH

Lights:

Headlight	12V 25W/25W
Taillight	12V 7W
Stop light	12V 23W
Flasher lights	12V 23W (optional parts)
Neutral light	12V 3W
Meter lights	12V 3W × 2
High beam indicator light	12V 1.5W
Flasher pilot light	12V 3W (optional parts)

1-3. Performance Curves




Fig. 1-3-1





Fig. 1-3-2

1-4. Service Tools

The following tools and instruments are required for shop servicing the YAMAHA 90HS1.


1. Standard Tools



- | | | |
|--|---------------------------------------|-----------------------------|
| 1. Plug wrench 23×29 mm | 2. Set of spanners | 3. Set of socket wrenches |
| 4. Soft-faced hammer | 5. Steel hammer | 6. Circlip pliers (ST type) |
| 7. Circlip pliers (RT type) | 8. Needle nose pliers | 9. Pliers |
| 10. Phillips-head screwdriver (medium) | 11. Phillips-head screwdriver (large) | |
| 12. Phillips-head screwdriver (small) | 13. Phillips-head screwdriver (small) | |
| 14. Slot-head screwdriver (medium) | 15. Slot-head screwdriver (small) | |
| 16. T-type socket wrench | | |

Fig. 1-4-1

2. Special Tools




- | | |
|-------------------------------------|--------------------------------------|
| 1. Clutch holding tool | 2. Crankcase dividing tool |
| 3. Crankshaft installing tool | 4. Flywheel magneto holding tool |
| 5. New type exhaust ring nut wrench | 6. Mitsubishi armature removing tool |

In addition, an electro-tester, tachometer (engine speedmeter), hydrometer, etc. are required.

Fig. 1-4-2

3. Other Miscellaneous Tools



1. Grease
2. Autolube oil
3. YAMAHA Bond (No. 5)
4. Wiping materials
5. Overhauling stand
6. Parts tray
7. Oiler
8. Oil jug


Fig. 1-4-3

Using a wooden box will facilitate engine service. Expendable parts (such as gaskets) and replacement parts must also be on hand.

CHAPTER 2. YAMAHA AUTOLUBE

2-1. What is YAMAHA Autolube?

The YAMAHA Autolube is an automatic lubricating device for 2-stroke engines. Developed by the YAMAHA Technical Institute, it meters oil to the engine with respect to engine speed and throttle opening by means of a precision pump. As a result, the YAMAHA engine does not require premixed gas and oil like other 2-stroke engines. Controlled lubrication is automatically applied to the working parts of the engine. This makes YAMAHA Autolube the best lubricating system ever-devised for 2-stroke engines. The oil pump is driven by the engine, through a reduction gear system and is also connected to the throttle.



YAMAHA Autolube

Fig. 2-1-1

www.legends-yamaha-enduros.com

2-2. Features of Yamaha Autolube

YAMAHA Autolube:

1. Eliminates the bother of pre-mixing gas and oil.
2. Maintains optimum lubrication according to both engine speed and throttle opening,
3. Reduces spark plug fouling by injecting just enough oil for proper lubrication.
4. Cuts oil consumption to $\frac{1}{3}$ that of conventional 2-stroke engines.
5. Reduces exhaust smoke.
6. Lets you use the engine compression as a brake; the oil injection system continues to operate according to engine RPM, even though the throttle may be closed.
7. Improves performance; no excess oil to interfere with complete combustion of the gas-air mixture.
8. Prolongs engine life; each injection is clean undiluted oil with high film strength, qualities often lacking in 2-stroke oils.

2-3. Handling the Oil Pump

The oil pump is a precision-machined assembly. Make no attempt to disassemble it. When you remove the oil pump from the engine, protect it from dust, dirt, etc. After reinstallation, be sure to bleed and test the pump correctly. Proper handling will keep the pump free from trouble.

1. Bleeding

When the oil pump has been removed (the oil line is disconnected), or when the oil tank is empty (e.g., a brand new machine), air enters the pump case, and interrupts the flow of oil, so the pump must be bled.

Remove the bleeder bolt, and rotate the starter plate (manual feed wheel) clock wise to feed oil through the pump. Hold the adjusting pulley back (pull the pump cable) to let the plunger pump at maximum stroke. As you turn the starter plate, oil will begin flowing out of the bleeder hole. When air bubbles no longer appear in the oil, you can install and tighten the bleeder bolt. (Fig. 2-3-1)



Fig. 2-3-1

2. Setting the Carburetor and Pump




Fig. 2-3-2

- (1) Start the engine and warm it up, then set the idle speed between 1,100 rpm and 1,200 rpm.
 - a. Be sure the pilot air screw on each carburetor is backed off $1\frac{1}{2}$ turns from a lightly seated position.
- (2) Adjust the throttle valves so that they lift simultaneously.
 - a. Remove all slack from the throttle cables B.
Adjust the throttle cables B with the throttle cable adjusting screw.

(Fig. 2-3-2)

To check the play in throttle cable B, grasp the cable, and move it up and down. If there is no play in the cable, engine idling speed will increase. Adjust both throttle valves so that they function simultaneously.

- b. Adjust the play of the throttle cable connected to the handle grip to 0.5~0.1 mm. Do this by turning the adjusting nut to the cable guide. (Fig. 2-3-3)




Fig. 2-3-3

- (3) After adjusting the throttle cable, set the oil pump correctly.

- a. Slowly open the handle grip until the play of the throttle cable is removed. (When the play is reduced to zero, the grip becomes somewhat tight). Adjust the pump cable so that the mark on the adjusting pulley is aligned with the guide pin.

(Fig. 2-3-4)




Fig. 2-3-4

- (4) Checking Minimum Pump (Plunger) Stroke.

- a. Stop the engine.
- b. Fully close the accelerator grip.
- c. Turn the oil pump starter plate in the direction of the arrow (marked on the starter plate) until the plunger moves to the end of its stroke. Then measure the narrowest gap between the adjusting pulley and the adjusting plate, using a feeler gauge.

- d. Correct Standards:

Minimum stroke limit	0.15mm
Proper tolerances	0.20-0.25mm

If the adjusting plate-to-pulley clearance is less than the minimum allowable stroke, remove the adjusting plate and install a 0.1 mm adjusting shim or shims to obtain correct clearance.

CHAPTER 3. 5-PORT CYLINDER

3-1. Description of 5-Port Cylinder

The Schnuerle loop scavenging system is the most commonly used induction system for two-stroke engines. In the schnuerle loop system, transfer ports on the right and left sides of the cylinder are employed to transfer 2 streams of fresh fuel in the loop design that had proved to be the most effective induction system until the innovation of Yamaha's 5-port cylinder. This conventional schnuerle loop system had a design limit in that the transfer ports could not be made large enough to completely clear the combustion chamber of exhaust gases because of the position of the intake and exhaust ports. This would result in a portion of exhaust gas remaining in the central area of the combustion chamber that would contaminate the fresh fuel charge.

The rotary valve induction system incorporates the use of a 3rd transfer port at the back of the cylinder that directs a fresh fuel charge to the dead area containing the remaining exhaust gases. But to incorporate the rotary valve system causes excessive engine width and unattractive appearance which restricts such an engine design.

Yamaha's Research and Engineering Departments, therefore, designed and perfected the five-port cylinder induction system that is used on the HS1. This new fiveport system with the incorporation of two additional specially designed transfer ports completely removes all the exhaust gases previously left in the dead area of the cylinder.

3-2. Construction and Features (Refer to Figs. 3-2-1,2 and 3)

The 5-port cylinder induction system is similar to the Schnuerle loop scavenging system in that the two main streams (a) of fresh fuel meet at the cylinder wall opposite the exhaust ports, and deflect upward. Then, the streams again deflect downward, forcing out the burnt gases through the exhaust ports.

Additionally, in the 5-port cylinder induction system, two auxiliary transfer passages are so arranged that these two ports run from the bottom of the cylinder up to the same height as the main transfer ports. Therefore, when the piston comes down to bottom dead center, these two transfer passages are open and fuel is pushed up from the crankcase to the cylinder.

In the conventional Schnuerle system of porting, the burnt gases (b) cannot be completely cleared out of the cylinder, remaining in the center of the combustion chamber as shown in Fig. 3-2-1. However, the design of the 5-port cylinder induction system has successfully eliminated such a disadvantage; the additional ports are designed to direct their fresh charge (c) at the area containing the remaining burnt gases, completely forcing the exhaust gases out of the cylinder.

Another advantage of the 5-port induction system is that the piston is cooled by the exhaust gases passing through it. This greatly increases the engine power in combination with the new design of 5-porting system.




Fig. 3-2-1




Fig. 3-2-2




Fig. 3-2-3 5-port Cylinder Exploded View

CHAPTER 4. ENGINE

The engine should be disassembled and reassembled in an orderly sequence to make your work easier and more efficient. The procedures outlined here are “examples” not inflexible rules for all repair jobs.

Caution on Engine Disassembling:

- Before removing the engine, clean the dirt and dust from the cylinder heads, cylinders and crankcase in order to keep these parts clean inside during disassembly and reassembly.
- Always use clean tools and use them correctly to avoid damaging parts.
- Keep disassembled parts in the parts trays and in separate groups or sub-assemblies so that no parts will be misplaced.

4-1. Removing the Engine

1. Drain the transmission oil after warming up the engine for a few minutes amount of oil 750—850 (Yamaha gear oil or motor oil SAE 10W/30 should be used)
2. Remove the mufflers and exhaust pipes. (Fig. 4-1-2)
3. Remove the foot rest, change pedal and crankcase cover (L) (Fig. 4-1-3)




Fig. 4-1-1




Fig. 4-1-2




Fig. 4-1-3

4. Remove the A.C. dynamo.
(Remove the wire harness).
(1) Remove the stator ass'y.




Fig. 4-1-4

- (2) Remove the cam.




Fig. 4-1-5

- (3) Remove the rotor by the use of the armature puller bolt.




Fig. 4-1-6

5. Remove the cleaner ass'y.




Fig. 4-1-7

6. Remove the throttle valves of both carburetors.




Fig. 4-1-8

7. Remove the crankcase cover (L).




Fig. 4-1-9

8. Disconnect the neutral light lead.
(Fig. 4-1-10)




Fig. 4-1-10

9. Remove the carburetor.
(Fig. 4-1-11)

www.legends-yamaha-enduros.com




Fig. 4-1-11

10. Remove the chain at the master link.
(Fig. 4-1-12)

The drive chain should be connected as shown in Fig.4-1-12a. After connecting the chain, have the rider sit on the motorcycle. Measure the up-and-down movement of the chain at the center of the lower chain run, and adjust it so that the total up-and-down movement of the chain is about 0.8 in. (20 mm)




Fig. 4-1-12




Fig. 4-1-12a

11. Disconnect the oil line from the oil tank bottom. (Fig. 4-1-13)

Install a plug in the oil tank outlet to prevent oil from flowing out.




Fig. 4-1-13

12. Remove the oil pump cable.
(Fig. 4-1-14)




Fig. 4-1-14

13. Remove the tachometer cable.
(Fig. 4-1-15)

www.legends-yamaha-enduros.com




Fig. 4-1-15

14. Remove the engine mounting bolts, and
remove the engine from the chassis.
(Fig. 4-1-16)




Fig. 4-1-16

4-2. Cylinder Heads

1. Removal and Reinstallation

Remove the nuts on the four cylinder stud bolts, (Fig. 4-2-1) then remove the cylinder head and cylinder head gasket. (Fig. 4-2-2)




Fig. 4-2-1

NOTE: As soon as the cylinders have been lifted high enough, stuff clean rags beneath the pistons to prevent dirt or contamination from falling into the engine. If the gaskets are damaged or defective, replace them.




Fig. 4-2-2

Remove the Banjo bolt (Fig. 4-2-3)




Fig. 4-2-3

2. Removing Carbon

Carbon accumulation inside the cylinder head results in pre-ignition, overheating, and excessive fuel consumption, so scrape the cylinder head clean. (Fig. 4-2-4)




Fig. 4-2-4

4-3. Cylinders

1. Removal

Remove the cylinder by tapping the cylinder fin with a plastic tip hammer, as shown in Fig. 4-3-1.




Fig. 4-3-1

2. Checking the Cylinder for Wear

1) In two-stroke engines, the maximum wear usually results in the upper area of the cylinder wall due to the side thrust of the piston, with less wear in the adjacent areas of transfer and exhaust ports. Measure each cylinder's bore diameter at four different depths (a, b, c, d) with a micrometer or a cylinder gauge placed in the direction of A and B. If the difference between the maximum and minimum diameters measured exceeds 0.05mm (0.0019 in.), rebore and hone the cylinder.




Fig. 4-3-2

(Figs. 5-3-3 and 4)

2) To make sure that the cylinder boring has been correctly done, measurements should be made as illustrated below. Measure each cylinder's bore diameter at three different depths (a, b, c) with a micrometer or a cylinder gauge placed at right angles and then parallel to the crankshaft (A and B).

(Fig. 4-3-4)

The minimum clearance between the piston and the cylinder is 0.035 to 0.040 mm.




Fig. 4-3-4




Fig. 4-3-3




Fig. 4-3-5

Cylinder Reconditioning

- a. Pistons are available in 0.25 mm and 0.50 mm oversizes.
- b. Cylinders should be rebored and honed to the diameter of the oversize piston, plus the standard clearance.
- c. The error between the maximum and minimum diameter after honing should be no more than 0.01 mm.




Fig. 4-3-6

3. Carbon Removal

Carbon tends to accumulate at the transfer and exhaust ports of the cylinder, thereby impairing both scavenging and exhausting efficiency. Be sure to remove carbon accumulations whenever necessary.

Avoid the use of files for carbon removal, because the carbon build-up can not be completely removed as shown in Fig. 4-3-6, or undesirable cuts in these ports may be the result. It is advisable to use a carbon scraper (B) and remove the carbon from every corner of the port. (Fig. 4-3-6)




Fig. 4-3-7

4. Installation

- a. Always use new cylinder gaskets when overhauling the engine. (Fig. 4-3-7)
- b. When installing the cylinder over the piston, squeeze the piston rings into their grooves (their end gaps should close on the knock pin) so they will not catch and break on the bottom of the cylinder. (Fig. 4-3-8)




Fig. 4-3-8

4-4. Piston Pins

1. Pulling Out the Piston Pin

Remove the clip at one end of the piston pin, using a needle nose pliers (Fig. 4-4-1), and push the pin out from the other side of the piston with a slit head screwdriver.

Before removing the piston pin clip, cover the crankcase opening with a clean rag so you will not accidentally drop the clip into the crankcase.



Fig. 4-4-1

2. Piston-to-Piston Pin Fit

The piston pin should fit snugly in its bore so that it drags a little as you push it. If the pin is loose, the pin and/or the piston should be replaced. A pin with step wear in its center should be replaced, along with the connecting rod small end needle bearing. (Fig. 4-4-2)

Check the small end of the connecting rod for wear by inserting the piston pin.





Fig. 4-4-2


4-5. Piston Rings

1. Keystone Type Piston and Keystone Ring



Plain type piston & piston ring

Fig. 4-5-1



Keystone type piston & piston ring

Fig. 4-5-2

A good seal must be maintained between the piston and cylinder wall for effective use of combustion pressures. It is not practical, however, to attempt to secure a perfect seal. With this in mind, importance is placed on effective sealing and prevention of piston ring sticking.

Piston ring sticking is generally caused by gum deposits which are produced through a break down of the fuel and oil from the heat of the combustion process. This gum residue will deposit itself in the ring lands and rings. The subsequent blow-by tends to speed up the accumulation of these gum deposits.

In order to prevent the rings from sticking and to provide more effective sealing of the combustion pressures Yamaha has employed the Keystone piston and ring in its engines. This marks the first time such an application has been made in the history of motorcycle engineering.

The design of the Keystone ring is such that combustion gas pressures force the ring down and out almost simultaneously. This forces the ring tightly against the cylinder wall preventing blow-by. (Fig. 4-5-3)

On the other hand, in the case of the plain ring, combustion pressure first acts on the top of the ring, forcing it down, and then passes between the ring and piston to force the ring against the cylinder wall. This action is considerably slower than that of the Keystone type ring, and will allow more blow-by.

With blow by, heat cannot be dissipated from the piston ring to the cylinder wall and, as was mentioned earlier, excessive combustion heat will cause the oil film to break down creating additional gum deposits. The Keystone ring allows for much better heat transference than the standard type ring.

The most important advantage of the Keystone type ring is that the piston ring land clearance changes as the piston moves up and down. Figs. 4-5-4 and 4-5-5 show variations in the clearance resulting from the floating action of the piston in the cylinder. This variation in ring land clearance produces a "scrubbing" effect that reduces the accumulation of gum deposits and thus prevents the ring from sticking in the land.

Lastly, the outer surface of the ring is coated with Teflon (Fig. 4-5-6). The Teflon coating serves as an effective aid during ring "seating". In addition, the Teflon coating will follow microscopic irregularities in the cylinder bore more faithfully than previous materials thus providing additional resistance against blow by.






Fig. 4-5-3



Side clearance when piston floats in the direction of the arrow.

Fig. 4-5-4



Side clearance when piston floats in the direction of the arrow.

Fig. 4-5-5




Fig. 4-5-6

TECHNICAL NOTES ON KEYSTONE RINGS

The keystone ring can be handled in the same manner as conventional rings as far as servicing is concerned. However, the keystone ring is not interchangeable and must be used as a set with a matching Keystone piston.

The Keystone ring can be identified from the conventional by its unique cross-sectional shape. The conventional ring has a rectangular cross-section where as the Keystone ring employs a 7° slope on the top.

IMPORTANT:

The Keystone type piston has the K mark stamped after the numerals indicating the piston sizes on its head. On the other hand, the Keystone type piston ring has a symbol such as "1(2)N", or "1(2)T".

(Numeral 1 denotes the top ring, and numeral 2 the second ring.)

2. Removing the Rings

Put your thumbs at each end of the piston ring and pull the piston ring ends apart. Then slide it out of the groove on the back side of the ring lands. (Figs. 4-5-7 and 8)



Fig. 4-5-7




Fig. 4-5-8




Fig. 4-5-9

www.legends-yamaha-enduros.com

3. Fitting the Rings

Both rings (top and bottom) are of the same type, and chrome plated. When installing the rings, align their ends with the knock pin. (Fig. 4-5-9)

4. Checking the piston Ring

1) Piston Ring Wear

Improper contact between the piston ring and the cylinder may result in compression leakage, or scores or spotty wear on the cylinder wall. Therefore, correct surface "contact" between the piston rings and the cylinder should be checked before the piston is installed. Fig. 4-5-10 shows an example of a method for checking the surface contact:




Fig. 4-5-10

Correctly fit the ring in the cylinder, and then check whether or not any gap is seen between the ring and the cylinder wall by using a sheet of white paper as a reflector. If no gap is found, a good sealing between them is maintained.

2) Measuring the piston ring for wear

Put the piston ring into the cylinder so that the ring is parallel with the bottom edge of the cylinder. Then measure the gap between both ends of the ring, using a feeler gauge. (Fig. 4-5-10)

End gap should be between 0.15 mm and 0.35 mm for both No. 1 and No. 2 rings.

3) Removing carbon deposits

Carbon on the piston rings and in the ring grooves will make the rings stick to the piston, thus impairing cylinder performance. Remove the piston ring, and clean the rings and the piston ring grooves.

4-6. Piston

1. Checking and Reconditioning the Piston

1) Piston Shapes

The piston has a slightly tapered ring section when it is cold, as shown in Fig. 4-6-1 left. When it warms up, the expansion of the ring section is greater than that of the skirt because the ring section is exposed to higher temperatures.

This decrease the normal clearance between the piston and cylinder wall, as shown in Fig. 4-6-1 right. When the piston is viewed from the bottom, its diameter at A (at the piston pin bosses) is slightly smaller than at B (right angles to the piston pin). At operating temperatures, the piston assumes a round shape, because the expansion at A is greater than B.




Fig. 4-6-1




Fig. 4-6-2

2) Piston Clearance Measurement

Piston clearance is the difference between the minimum cylinder bore and the maximum piston diameter.

Proper clearance is between 0.035~0.040 mm (0.00139~0.00160 in.) as described in the "Cylinder" section. To determine maximum piston diameter, measure the piston with a micrometer at right angles to the pin bosses 10 mm from the piston bottom edge, as shown in Fig. 4-6-3.




Fig. 4-6-3

3) Checking and Reconditioning Pistons

Pistons showing signs of seizure are noisy and keep the engine from developing full power. If a piston that has seized is used again without any correction, another seizure will develop at the same point. Lightly sand these seizure area on the piston areas showing excessive friction with #400 sandpaper. (Figs. 4-6-4 and 5)



Fig. 4-6-4



Fig. 4-6-5

4) Removing Carbon

Scrape off carbon accumulation on the top of the piston using a screwdriver or a hacksaw blade. (Fig. 4-6-6)

Take note that the piston is not damaged during this process.

Scrape off carbon accumulation in the piston ring grooves in order to prevent the ring from sticking. Do not use an old broken ring. The HS1 uses Keystone pistons and an old ring will not fit within the ring land. (Fig. 4-6-7)




Fig. 4-6-6



Fig. 4-6-7

2. Piston Installation Direction

Install each piston with the arrow marked on its head pointing downward (toward the exhaust port of the cylinder). (Fig. 4-6-8)




Fig. 4-6-8

4-7. Crankcase Cover (R)

1. Removal

a. Remove the kick starter crank clamping bolt, and remove the crank. (Fig. 4-7-1)

b. Remove the pan-head screws from the crankcase cover (R), and take off the cover. (Figs. 4-7-2 and 3)

(The right crankcase cover may be removed with the oil pump mounted on it, after disconnecting the oil delivery lines.)




Fig. 4-7-1




Fig. 4-7-2




Fig. 4-7-3

c. Always new gasket should be used when overhauling the engine.




Fig. 4-7-4

2. Reinstallation

Coat the right crankcase sealing surface with gasket paste (YAMAHA BOND No. 5), lay the crankcase cover gasket over it, and then replace the right crankcase cover. (Fig. 4-7-5)

Be sure to apply the bond; otherwise, oil may leak.




Fig. 4-7-5

4-8. Tachometer Drive Gear Assembly

1. Tachometer drive gear assembly components.




Fig. 4-8-1

4-9. Clutch

The purpose of the clutch is to permit the rider to couple or uncouple the engine and transmission. The HSI clutch is a wet multi-disk type, consisting of four molded cork friction plates and four clutch plates mounted on the main axle of the transmission.

The clutch housing is mounted on the primary driven gear, which in turn is meshed with the primary drive gear that is mounted on the crankshaft. The primary drive gear has 19 teeth, and the primary driven gear has 74 teeth. (Primary reduction ratio $74/19=3.894$)




Fig. 4-9-1




Fig. 4-9-2

- | | |
|------------------------------|-----------------------------------|
| 1. Primary driven gear ass'y | 10. Clutch spring-5 |
| 2. Friction ring | 11. Clutch spring holding screw-5 |
| 3. Thrust bearing | 12. Spacer |
| 4. Thrust plate | 13. Kick pinion gear |
| 5. Clutch boss | 14. Thrust plate 1 |
| 6. Clutch plate-5 | 15. Push rod 1 |
| 7. Cushion ring-5 | 16. Lock nut |
| 8. Friction plate-5 | 17. Lock nut washer |
| 9. Pressure plate | |

NOTE: Figure following part name indicates quantity necessary for one complete assembly.

1. Removing the Pressure Plate

Remove the five clutch spring screws, the springs, and the pressure plate. (Fig. 4-9-3)




Fig. 4-9-3

2. Checking the Clutch Spring

Measure the free length of each clutch spring, and replace any spring more than 1.0 mm shorter than the standard free length. (Figs. 4-9-4 and 5)



Fig. 4-9-4




Fig. 4-9-5

3. Checking the Friction Plate

Friction plates are designed to wear, so plates worn more than 0.3 mm under the standard thickness (4.0 mm), or showing uneven contact with the clutch plates. Should be replaced. (Figs. 4-9-6 and 7)

Standard 4.0 mm
(0.157 in.)




Fig. 4-9-6




Fig. 4-9-7

4. Fitting the Cushion Rings

The cushion rings are installed between each clutch friction plate pair to insure even engagement of the plates. When fitting cushion rings, be sure they are flat and not twisted. (Fig. 4-9-8)




Fig. 4-9-8

5. Removing the Clutch Boss

Pull out push-rod 1 and straighten the bent edges of the clutch boss locking washer. Fit the clutch holding tool over the clutch boss, remove the nut, and then the boss itself. (Figs. 4-9-9 and 10)




Fig. 4-9-9




Fig. 4-9-10

6. Checking the Primary Driven Gear Ass'y

Insert the spacer in the primary driven gear boss, and check it for radial play or scratches that could impair clutch action and result in excessive noise. Remove the scratches with an oilstone or fine sandpaper. (Fig. 4-9-11)




Fig. 4-9-11

7. Checking the Spacer

Place the spacer on the main axle, and check it for radial play. If play exist replace the spacer. (Fig. 4-9-12)
(The spacer with step wear in its outside should be replace, too.)




Fig. 4-9-12

8. Checking the Push Rod

Remove the push-rod from the clutch boss and roll it over a surface plate. If the shaft is bent, straighten or replace it. (Fig. 4-9-13)

www.legends-yamaha-enduros.com




Fig. 4-9-13

9. Caution on Reassembling the Clutch

On the clutch side of the primary driven gear there is a thrust plate and a thrust bearing. If the thrust plate and thrust bearing are incorrectly fitted, or omitted, the clutch boss will ride against the outer clutch housing and prevent smooth clutching. Be sure the thrust bearing and plate are correctly installed when reassembling the clutch. (Figs. 4-9-1 and 2).

The thrust bearing is placed around the primary gear spacer. When installing the clutch boss, exercise care not to slip the thrust bearing from the spacer.

Grease the surface of the thrust bearing that goes against the outer housing to hold the bearing in place.

10. Clutch Adjustment

The friction plate and clutch plate, which are component parts of the clutch, are liable to wear after years of use. The wear of these parts results in poor clutch action or clutch slippage. Replace or correct them if worn.

(1) Adjusting the Adjusting Screw.

(Fig. 4-9-14)

- a. Remove the dynamo cover located on the left side of the crankcase cover.
- b. Loosen the adjusting screw lock nut as shown in Fig. 4-9-14.
- c. Slowly tighten the adjusting screw until resistance is felt. This means that the play of the push rod is removed. Then, back it off a 1/4 turn. Tighten the lock nut.




Fig. 4-9-14

(2) Adjusting the Clutch Cable

- A. This adjustment is made on the left upper part of the crankcase cover.

(Refer to Fig. 4-9-14)

- a. Loosen the clutch cable adjusting screw lock nut.
- b. To reduce the play of the cable, loosen the adjusting screw, and to increase the play, tighten the screw. Adjust clutch lever free play to 2~3 mm. (Fig. 4-9-15)
- c. Fully tighten the lock nut,




Fig. 4-9-15

- B. Adjustment on the upper part of the clutch cable. (Refer to Fig. 4-9-15).

- a. Loosen the lock nut.
- b. To decrease the play of the clutch cable, turn the cable adjusting screw clockwise, while to increase the play, turn the screw counterclockwise. If the play is between 2 to 3 mm, the cable is adjusted properly.

4-10. Primary Drive Gear

1. Removal

- Feed a rolled-up rag between the teeth of the primary drive gear and the primary driven gear to lock them. (Fig. 4-10-1)
- To remove the gear, use two slot-head screw-drivers in the manner as shown in Fig. 4-10-2.




Fig. 4-10-1

2. Checking

Excessive backlash between gear teeth causes a clashing noise, while insufficient backlash results in a whine.

To measure the backlash, use a dial gauge or a special gauge. For convenience of this measurement, numbers are marked on the surfaces of the primary drive gear and the primary driven gear. make a combination of these two gears so that the total of numbers reaches a specified set value.




Fig. 4-10-2

Standard Value:

TOTAL OF NUMBERS 150 ± 1

Check the gears for scratches, wear and shaft-to-hole fit, and replace worn parts. If the replacement of worn parts does not cure the clashing noise or whine adjust gear backlash by means of increasing or decreasing the standard value (total of numbers).

4-11. Distance Collar

Remove the distance collar from the crankshaft, using your fingers or pliers. When reinstalling the distance collar, first put an adequate amount of grease in the lip cavity of the crankshaft oil seal.

Be sure to install the collar with its chamfered end inward.

4-12. Kick Starter




Fig. 4-12-1 Kick Cross Section

Mechanism

The primary kick-starter system (one-touch kick-starter) is employed. However, a new "non-constant-mesh" mechanism has been introduced into the HS1 kick-starter, instead of the constant-mesh kick gear type, such as the ratchet and roller-lock systems.

That is, the kick gear meshes with the idler gear only when the kick-starter pedal is kicked. After the engine is started, the kick gear is disengaged from the idler gear. This mechanism not only eliminates noise resulting from the constant mesh of the kick gear with the idler gear, but also greatly contributes to the durability of the kick starter assembly.

As the kick starter axle is turned, the kick gear splined to the kick axle, having spiral splines on its surface, is slid upward along the axle. (In this case, the kick gear moves only axially without rotating because of the kick gear clip fitted in the kick gear.) When the kick gear moves upward, teeth of the kick gear may clash against teeth of the idler gear. (Although there will be possibility of smooth meshing without clashing.) The kick gear clip is designed to absorb the impact of clashing, and at the same time cause the kick gear to rotate so that the kick gear will smoothly come into mesh with the idler gear.

(Refer to Figs. 4-12-2 and 3) After the kick gear has meshed with the idler gear, the kick gear is further slid upward without rotating. At the instant that the back of the kick gear contacts the circlip, the thrust load is imposed on the kick gear, thereby giving it turning force and rotating the crankshaft to start the engine.




Fig. 4-12-2





Fig. 4-12-3



- ① Kick-starters shaft
- ② Kick gear
- ③ Adjusting shim
- ④ Circlip
- ⑤ Kick return spring guide
- ⑥ Kick return spring
- ⑦ Kick return spring cover
- ⑧ Circlip

Fig. 4-12-4 Exploded View of the Kickstarter

1. Removal

The kick starter system can be removed as an assembly. (Fig. 4-12-5)




Fig. 4-12-5

2. Removing the Kick Idler Gear

Remove the circlip retaining the idler gear with pliers. Remove the thrust washer, and then slide the gear off the drive axle. (Fig. 4-12-6)




Fig. 4-12-6

4-13. Drive Sprocket

www.legends-yamaha-enduros.com

1. Removal

- a. Straighten the bent edge of the locking washer with a chisel. (Fig. 4-13-1)




Fig. 4-13-1

- b. Keep the drive sprocket from turning with the flywheel magneto holding tool, then loosen the sprocket nut. (Fig. 4-13-2)




Fig. 4-13-2

- c. If no flywheel magneto holding tool is available, shift the transmission to 1st gear, fit a socket wrench on the sprocket nut, and hit the handle of the wrench with a hammer so the impact will loosen the nut.

2. Checking the Drive Sprocket

A worn drive sprocket may result in abnormal noise, and shorten the life of the chain. Check the teeth of the sprocket teeth for wear and deformation.

Checking the Chain and Drive Sprocket for Meshing:

Drive sprocket wear can be checked by inspection the teeth, but it can more easily be checked by observing the meshing of the sprocket with the chain.

Whether the drive sprocket is worn or not can be determined by using a new drive chain. If there is excessive play between the sprocket and the new chain, replace it. (Figs. 4-13-4)




Fig. 4-13-3

Clean the chain with solvent before checking it. Then hold the chain in your fingers, as shown in Fig. 4-13-5 and check whether the chain bends without kinking.

Next, suspend the chain as shown Fig. 4-13-7. If the chain exhibits curvatures, (A, B and C) as shown in Fig. 4-13-7, it is defective. Replace it.

Curvatures may often result from lack of lubrication, dirt, or rust. In this case, reclean the chain and repeatedly bend it back and forth in detergent oil, then check it again for defects.

Another good test for wear is to mesh the chain with a new sprocket and check for excessive slack. The chain is bad if you can pull it away from the curvature of the sprocket a distance of more than a $\frac{1}{2}$ link.




Fig. 4-13-4



Fig. 4-13-5



Fig. 4-13-6




Fig. 4-13-7

4-14. Shifting Mechanism




Fig. 4-14-1

www.legends-yamaha-enduros.com

When the gear shift lever is depressed, the gear shift moves gear shift arm B back and forth, which in turn causes, gear shift arm A to push the gear shift drum pins mounted on the gear shift drum, thus turning the gear shift drum.

The gear shift drum is equipped with five gear shift drum pins, and is designed to make $\frac{1}{5}$ of a turn each time the gear shift lever is depressed. In other words, one full turn of the drum will shift the transmission through five stages; first, second, third, fourth and fifth. The gear shift pins are held by the disc so that the stopper plate may secure each position of the five stages.

The outer surface of the gear shift drum is provided with slots, along which the shift forks travel back and forth when shifting gears.

The neutral position is located between the first and second gear shift drum pins, and the stopper mechanism is located on the left side of the shift drum.

1. Removing the Gear Shift Shaft Ass'y

To remove gear shift arm A, remove the circlip and washer. (Fig. 4-14-2) Lift up gear shift arm from the shifter drum, and remove it from the right side of the engine. (Fig. 4-14-3)




Fig. 4-14-2




Fig. 4-14-3

2. Checking Gear Shift parts

- a. Checking the gear shift return spring
Check the gear shift return spring for fatigue or damage. A broken or fatigued gear shift return spring will impair the returning action of the shifting action of the shifting system.
- b. A broken or fatigued gear shift arm spring will result in shifting failures.




Fig. 4-14-4

3. Gear Shift Arm

www.legends-yamaha-enduros.com

a. Removal

First remove the mounting bolt and remove the spring one by one.

b. Checking the gear Shift Arm Spring (Refer to Fig. 4-14-5).

A fatigued or broken gear shift arm spring may let the shift arm slip from one shifter drum pin to another. Check the spring for proper tension and replace it if weak or broken.




Fig. 4-14-5

4. Reconditioning

If the shifting assembly does not work correctly (e.g., slippage or shifting half-way), adjust the gear shift return spring stop screw (eccentric shaped screw) to correct the shift arm action. (Fig. 4-14-6)




Fig. 4-14-6

4-15. Splitting the crankcase

1. Splitting

The crankcase may be split from either the left or right side. However, to facilitate the subsequent servicing operations, the splitting tool should be installed on the right half of the crankcase.

- a. Remove the pan head screws on the left side crankcase. (Fig. 4-15-1)
- b. Install the crankcase dividing tool on the right crankcase and alternately tap the transmission main axle and the side of the right half with a soft faced hammer, so that the right half eventually separates completely from the left half. (Figs. 4-15-2 and 3)




Fig. 4-15-1




Fig. 4-15-2




Fig. 4-15-3

- Note:
1. Fully tighten the bolts of the crankcase dividing tool, while keeping the body horizontal.
 2. Position the connecting rod at top dead center to prevent the rod from contacting.

2. Reassembling

When reassembling the crankcase, be sure to clean the mating surfaces thoroughly and then apply YAMAHA BOND No. 4 to the mating surfaces of the crankcase. (Fig. 4-15-4)




Fig. 4-15-4

4-16. Transmission Ass'y




Fig. 4-16-1 Layout of Transmission Gears

www.legends-yamaha-enduros.com




Fig. 4-16-2 Exploded View of Transmission

For details of assembly, arrangement and parts of the transmission, refer to Figs. 4-16-1 and 2.

The primary reduction ratio is 74/19 (3.894), and the secondary reduction ratio is 40/13 (3.077). Therefore, the total reduction ratios will be:

	Primary reduction	Transmission gear reduction	Secondary reduction	Total reduction ratio
Low	74/19 (3.894)	3.182 (35/11)	3.077 (40/13)	38.126
2nd	“ “	1.813 (29/16)	“ “	21.723
3rd	“ “	1.300 (26/20)	“ “	15.576
4th	“ “	1.045 (23/22)	“ “	12.521
5th	“ “	0.840 (21/25)	“ “	10.065

1. Removal

- 1) Remove the circlip, holder, and washer from the gear shift drum on the left side of the engine. (Figs. 4-16-3 and 4)




Fig. 4-16-3




Fig. 4-16-4

- 2) Remove the neutral, stopper mechanism. (Figs. 4-16-5, 6)




Fig. 4-16-5




Fig. 4-16-6

- 3) Remove the transmission and shifter as a unit. (Fig. 4-16-7)




Fig. 4-16-7

2. Caution on Reinstallation

- a. Reinstalling the Gear Ass'y and Shifter
Reinstall the transmission and shifter as a unit in the left crankcase half after they are sub assembled. Remember that the gear ass'y and shifter drum can not be installed separately. (Fig. 4-16-8)
- b. Caution on Reassembling the Crankcase
The following measures should be taken to prevent the shift forks from bending.




Fig. 4-16-8

- Never reassemble the crankcase halves, with the transmission in first gear. Otherwise, the fifth pinion dog may batter against wedge the pinion teeth, and cause the shift fork to bend.

4-17. Crankshaft

Of all the engine parts, the crankshaft requires the highest degree of accuracy in engineering.

The crankshaft oil seal in the YAMAHA 90HS1 is a solid aluminum, laby rinth type, which is superior to the conventional type in resistance to heat, oil and wear.




Fig. 4-17-1 Crankshaft Ass'y Component Parts




Fig. 4-17-2 Assembled Crankshaft Dimentions

1. Removing the Crankshaft Ass'y

- a. Remove the crankshaft ass'y with the crankcase dividing tool. (Fig. 4-17-3)
 - Tighten the dividing tool bolts into the crankcase, and keep the crankcase horizontal.
 - Pull the connecting rod up to top dead center so it will not hit the crankcase, and keep it there by inserting a thrust bearing between the end of the crankshaft and the center bolt of the dividing tool.




Fig. 4-17-3

2. Disassembling the Crankshaft Ass'y

To disassemble the crankshaft ass'y use a set of special tools as shown in Fig. 4-17-4, and follow the steps 1)~8).

www.legends-yamaha-enduros.com




Fig. 4-17-4

- 1) Insert the tool (1) into the gap between the crank wheel and the crank cover. (Fig. 4-17-5)
Then install the tool (2) in the same manner as above on the other half of the crankshaft.




Fig. 4-17-5

- 2) Fully tighten the bolts of tool (1) and (2). Failure to tighten the bolts completely can result in tool failure. (Fig. 4-17-6)




Fig. 4-17-6

- 3) Fig. 4-17-7 shows the tools installed on the crankshaft ass'y.




Fig. 4-17-7

- 4) Hold the crankshaft ass'y in a vice, and disassemble the ass'y into two parts by alternately giving one turn to each bolt (3) which is installed on the tool (2), so that the crankshaft ass'y splits into two parts. (Fig. 4-17-8)




Fig. 4-17-8

- 5) Fig. 4-17-9 shows the disassembled crankshaft ass'y. To remove the crank cover and bearing, use a press. Note that the ignition side was removed. This allows free made center spline to protrude and provide an easier working surface for the press.




Fig. 4-17-9

- 6) Remove the crankshaft pin in the manner as shown in Fig. 4-17-10. (For this purpose, use the jigs as shown in Fig. 4-17-11)
- 7) Next, take the remaining crank wheel with the crank pin still in it, turn the wheel over, place it on the support plates, and press out the crank pin.
- 8) Repeat steps "6)" and "7)" to disassemble the other crank half.



Fig. 4-17-10

3. Reassembling the Crankshaft Ass'y

To reassemble the crankshaft ass'y use a set of special jigs as shown in Fig. 4-17-11.

www.legends-yamaha-enduros.com




Fig. 4-17-11

- 1) Install Tool No. 6 (used to space the crankshaft. ass'y) on Tool No. 1. (Fig. 4-17-12)




Fig. 4-17-12

- 2) Press the crank pin into one crank wheel, and position the crank wheel in Tool No. 1. Then install the connecting rod on the shaft. (Fig. 4-17-13)




Fig. 4-17-13

- 3) Place the other crank wheel in position and lightly tap it onto the crank pin. Keep the crank wheel horizontal when tapping it in place.

Position the slide plate against the rim of the crank wheel, and tap the slide plate until it contacts the crank wheel (to align the crankshaft temporarily) using a brass hammer. (Fig. 4-17-14)




Fig. 4-17-14

www.legends-yamaha-enduros.com

Note: When using the hammer, keep the slide plate bolt lock nut loose.

- 4) Tighten the slide plate lock nut fully. (Fig. 4-17-15)




Fig. 4-17-15

- 5) Place Tool No. 2 on the face of the crank wheel and press the wheel downward with a hand press until Tool No. 2 comes in contact with the top of Tool No. 6. Then continue pressing until the pressure load reaches 5 tons. (Fig. 4-17-16)

(Pressure should be applied in the center line of the crank pin. Fig. 4-17-16)




Fig. 4-17-16




Fig. 4-17-17

- 6) First, install the crank cover over the male center spline. Then join the two crank halves together, making sure the rods are 180° apart. Note that tool No. 5 (crankshaft wedge) is placed between the upper crank wheels to prevent the crank wheels from collapsing against the rods. When you are sure the center splines are mating correctly apply pressure on the order of 10 (+) tons.

Remove the crankshaft and check overall width. If overall width is correct the entire crank assembly may now be aligned. (Fig. 4-17-18)

Then align the whole crankshaft ass'y.




Fig. 4-17-18

4. Aligning Crankshaft Ass'y

- 1) Place the crankshaft ass'y on V blocks or other suitable centering device and check for alignment. (Fig. 4-17-19)
If runout exceeds specified limits, align the crankshaft ass'y.




Fig. 4-17-19

- 2) To correct crank wheel runout drive a wedge into the gap between the crank wheels, or use a brass hammer to tap the wheels into alignment.
(Figs. 4-17-20 and 21)



Fig. 4-17-20




Fig. 4-17-21

5. Accuracy of the Crankshaft Ass'y

- 1) Axial Play of the Connecting Rod Small End

(Measure the wear of the crank pin and bearing at the large end of the connecting rod.)

As shown in Fig. 4-17-22, wiggle the connecting rod small end, and check for axial play.

Axial play limits:

www.legends-yamaha-enduros.com

- (a) Axial play should be 2 mm or less.
(Use a dial gauge.) If the play is more than 2 mm, disassemble the crankshaft and replace defective parts.
- (b) After reconditioning, axial play should be between 0.8 mm and 1.0 mm.




Fig. 4-17-22

- 2) Checking the Connecting Rod for Large End Side Play. (Fig. 4-17-23)

Hold the connecting rod to one side and insert a feeler gauge between the large end and the crank wheel.

Side Play Limits: 0.1 mm 0.3 mm




Fig. 4-17-23

3) Overall Length and Runout of the Crankshaft (Fig. 4-17-24)

Limits:

(a) Overall length of the Crank

A 43 $\begin{matrix} -0.05 \text{ mm} \\ -0.10 \text{ mm} \end{matrix}$

B 126 $\begin{matrix} -0 \text{ mm} \\ -0.20 \text{ mm} \end{matrix}$

(b) Runout of the Crankshaft

0.03 mm or less




Fig. 4-17-24

6. Reinstalling the Crankshaft Ass'y

Put shims on both ends of the crankshaft, and install the crankshaft assembly by using the crankshaft installing tool.

Hold the connecting rod at top dead center with one hand while turning the handle of the installing tool with the other.

(Fig. 4-17-25)





Fig. 4-17-25

4-18. Bearings and Oil Seals ends-yamaha-enduros.com

LEFT HALF

RIGHT HALF



- | | | |
|------------------------------|-----------------------|-----------------------|
| 1. Bearing (6304C3) | 2. Oil seal (SD20408) | 3. Needle bearing |
| 4. Push rod seal (SD08226) | 5. Bearing (#6304) | 6. Oil seal (SD28447) |
| 7. Bearing (#6304C3) | 8. Oil seal (SW28408) | 9. Bearing (#6303) |
| 10. Needle bearing (SD20408) | | |

Fig. 4-18-1 Installation Position of Bearings and Oil Seals

1. Removal and Reinstallation

Ideally, the crankcase should be heated slowly and evenly to approximately 120°C (248°F) to remove or install oil seals and bearings, but the following procedure is satisfactory.

1) Removal

- a. Pry the oil seals out of place with slot-head screwdriver.

(Fig. 4-18-2)

When overhauling the engine, always replace the oil seals.




Fig. 4-18-2

- b. Remove the bearings with the bearing removing tool. (Fig. 4-18-3)

www.legends-yamaha-enduros.com





Fig. 4-18-3

2) Reinstallation

Install all bearings and oil seals, with the stamped marker's mark or numbers facing outward.

Pack all bearings with an adequate amount of light weight grease before installation.

4-19. Carburetors



The YAMAHA 90HS1 engine is equipped with a pair of AMAL type, MIKUNI VM16SC carburetors.

Fig. 4-19-1

1. Pilot jet
2. Valve seat washer
3. Valve seat assy
4. Main nozzle
5. Main jet
6. Float
7. Float pin
8. Float chamber gasket
9. Float chamber body
10. Body fitting screw
11. Nut
12. Air adjusting screw
13. Air adjusting spring
14. Throttle valve
15. Throttle bar
16. Cotter pin
17. Needle
18. Clip
19. Spring seat
20. Throttle valve spring
21. Mixing chamber top
22. Mixing chamber cap
23. Wire adjusting nut
24. Wire adjusting screw
25. Throttle stop spring
26. Throttle screw
27. Cap
28. Starter plunger
29. Plunger spring
30. Starter lever(left)
31. Starter lever(Right)
32. Starter lever rod
33. Rod screw
34. Starter lever washer
35. Starter lever plate
36. Plunger Cap
37. Plunger cap cover
38. Air bent pipe
39. Plate
40. Spring washer
41. Panhead screw
42. Over flow pipe




Fig. 4-19-2 Carburetor Components

1. Checking the Carburetor

1) Float

If fuel leaks into the float while the engine is running, the float chamber fuel level will rise and make the combustion mixture too rich. Shake the float so you can feel or hear any gasoline inside. Replace the float if it is deformed or leaking.

2) Float Valve

Replace the float valve if its seating end is grooved or scratched. Check the float valve spring for fatigue. Depress the float valve with your finger, and make sure it properly seats against the valve seat.

If the float valve spring is weakened, fuel may overflow, flooding the float chamber when the machine is running at certain speeds, or over a certain type of road.

3) Overflowing

If fuel overflows, check the carburetor as described in 1) and 2) above. If neither 1) nor 2) cures the overflowing, it may be caused by dust or dirt in the fuel preventing the float valve from seating properly. Remove the dust or dirt in the fuel. (Figs. 4-19-3 and 4)




Fig. 4-19-3




Fig. 4-19-4

4) Cleaning the Carburetor

Disassemble the carburetor, and wash all its parts in a suitable solvent. Blow all air and fuel passages in the carburetor with compressed air.

All jets and other delicate parts should be cleaned by blowing compressed air through them, because wire or other hard, pointed cleaning tools may damage their precision-machined surfaces.

(Fig. 4-19-5)




Fig. 4-19-5

2. Adjusting the fuel

The fuel level of the carburetor is strictly checked out before delivery of the machine, but it may fluctuate because of a worn needle valve or a deformed float arm.

If the fuel level rises above the specified level, the air-fuel mixture becomes too rich. If the fuel level is below the specified level, the mixture becomes lean. Any incorrect fuel level should be adjusted in the following manner.




Fig. 4-19-6




Fig. 4-19-7

- 1) Remove the float chamber body, and invert the mixing chamber body. Slowly push the float downward with your fingers until the float contacts the top of the float needle. Do not push hard enough to compress the needle valve spring.
- 2) Then measure height A in Fig. 4-19-6 (From the top of the float to the float chamber gasket seat.)
Standard measurement: 24 ± 1 mm.
- 3) If A measure more or less than the standard value, bent the tang a little so that a correct measurement is obtained.

3. Synchronizing Carburetors

Both cylinders will not pull evenly unless the carburation system for each side is identical. If one slide is higher in the carburetor bore than the other slide, overall poor engine performance will be the result.

1. With the engine not running, remove the rubber air filter connectors.
- 2) Twist the throttle grip fully open so that the slides lift completely up.

- 3) Reach into the air intake of both carburetors with the fingers of one hand (a side angle mirror placed in front of the air intakes will also allow the slide positions to be checked) and feel the top of the bores for the throttle slides.
- 4) Slowly close the throttle grip until the throttle slides just begins to enter the bore.
- 5) Both slides must be synchronized to enter the bore at exactly the same time. If the slides are not synchronized, then make an adjustment at the top of the carburetor, using the cable adjuster, to raise or lower one slide to match the other.

4. Adjusting the Idle Speed

- 1) Turn the throttle stop screws equally, a couple turns, to raise the throttle slides from a fully closed position. This prevents the engine from quitting while the idle speed is being adjusted.
- 2) Start the engine.
- 3) Begin with either carburetor and alternately screw the idle speed screw in, then out. While doing this, take note of the increase and decrease in engine rpm. At the point where both cylinders are idling at the same speed there will be no increase and decrease in engine rpm for approximately $\frac{1}{2}$ ~1 turns. At this point the idle rpm may exceed the specified rpm, but this can be corrected by backing off both idle speed screws an equal amount until the rpm's drop to the proper level (1,100~1,200 rpm's.)

5. Carburetor Setting

	Model	HS1 General
1.	M. J. (Main jet)	#70
2.	N. J. (Needle jet)	E-0
3.	J. N. (Jet needle setting the step where J. N. clip is fitted)	3G9-4
4.	C. A. (Throttle valve cutaw v)	1.5 (13φ)
5.	P. J. (Pilot jet)	20
6.	A. S. (Air screw setting-the number of turns the A. S. is backed off from a lightly seated position)	1 $\frac{1}{2}$
7.	G. S. (Starter jet)	#30
8.	Idling Speeds (RPM)	1,100~1,200

4-20. Air Cleaners

1. Removal

- 1) Remove the side covers, both right and left.
- 2) Remove the air cleaner mounting bolt.
- 3) Loosen the screw both right and left.
- 4) Remove the cleaner assy and take out the filter element.




Fig. 4-20-1




Fig. 4-20-2

2. Cleaning

Clean the filter element with compressed air.

Because the element is made of filter paper, it should never be exposed to water or oil.

If the element is excessively dirty, it may be cleaned carefully with gasoline. If possible, the element should be replaced every 3,000 miles (5,000 km).




Fig. 4-20-3

CHAPTER 5. CHASSIS

The chassis is of a steel tubing diamond frame structure. The HS1 has successfully reduced the number of members of the frame, thereby attaining a well-balanced stress distribution. The unique design of the chassis has resulted in lighter weight as well as in improved rigidity and strength.

5-1. Front Wheel




Fig. 5-1-1 Front Wheel Components

1. Removal

- 1) Disconnect the brake cable from the front brake shoe plate, and remove the speedometer cable. (Fig. 5-1-2)




Fig. 5-1-2

- 2) Remove the front wheel shaft nut. (Fig. 5-1-3)




Fig. 5-1-3

- 3) Loosen the front wheel shaft lock bolt. (Fig. 5-1-4)




Fig. 5-1-4

- 4) Pull out the shaft. (Fig. 5-1-5)




Fig. 5-1-5

5) Remove the front wheel ass'y (Fig.5-1-6)



Fig. 5-1-6




Fig. 5-1-7

2. Checking and Adjustment

1) Checking the Runout of the Rim

Anchor the front wheel as shows in Fig. 5-1-7, and measure the runout of the rim with a dial gauge.

Runout limits: 2 mm (0.07 in.)

Excessive runout of the rim may cause steering difficulties while riding the machine, which may lead to an accident.

Excessive runout may result from a deformed rim or a loosen spoke nipple.

2) Spokes

a. Replacing Spokes:

When replacing a spoke or lacing up a new wheel it must be noted that there are two different spokes used on the rim assembly. Figure 6-1-8 (left) shows an "outside" spoke and (right) an "inside". When lacing up a new wheel assembly, always install the "inside" spokes first then true the wheel.

After the wheel has been roughly trued, install the outside spokes and align the wheel to final specifications.

b. Adjusting the spoke tension;

Any loosened spoke or uneven spoke tension may cause the rim to warp.

This may also adversely affect the spoke itself. Spokes tend to become




Fig. 5-1-8




Fig. 5-1-9

loose after many miles. This is particularly true with a new machine. Therefore, the spokes should be retightened periodically.

Retightening should be performed by giving each nipple one turn, beginning with one side of the hub and then the other side.

Spoke nipple tightening torque: 15 kg-cm (Fig. 5-1-9)

3) Brake Shoe

Set the brake shoe, and measure the outer diameter of the shoe, using a slide calipers, as shown in Fig.5-1-10. If the shoe is less than 105 mm (4.14 in.), replace it.




Fig. 5-1-10

4) Brake Drum

Oil, dust or scratches on the inner surface of the brake drum will result in abnormal noise or a malfunction of the brake. Clean or smooth out the surface with a rag or sandpaper. (Fig. 5-1-11)




Fig. 5-1-11

5) Repairing the Brake Shoe

If the brake shoe has scratches or uneven contact with the brake drum, smooth out the surface with sandpaper or hand file. (Fig. 5-1-12)




Fig. 5-1-12

6) Replacing the Clutch Hub Bearing

- a. First remove the sprocket shaft by pushing it out toward the other side.
- b. Remove the sprocket shaft collar. (It can easily be pulled out with your hand.)
- c. Remove the oil seal. Exercise care not to damage the oil seal.
- d. Remove the circlip.

- e. Use the bearing fitting tool to push out the clutch hub bearing toward the sprocket side.
- f. To install the clutch hub bearing, reverse the above sequence. Before installation, grease the bearing and oil seal.




Fig. 5-1-13

7) Replacing the Wheel Bearing

- a. First, clean the outside of the wheel hub.
- b. Insert the bent end of the special tool (as shown in Fig. 5-1-15) into the hole in the center of the bearing spacer, and drive the spacer out of the hub by tapping the other end of the special tool with a hammer. (Both bearing spacer and spacer flange can easily be removed.)
- c. Push out the bearing on the other side.
- d. To install the wheel bearing, reverse the above sequence. Be sure to grease the bearing before installation and use the bearing fitting tool (furnished by Yamaha.).




Fig. 5-1-14



Insert the bent end of the special tool into the hole in the center of the bearing spacer.

Fig. 5-1-15

- 8) Replace a bent or damaged front wheel axle.
- 9) If the tooth surface of the helical speedometer drive gear is excessively worn, replace it.
- 10) Check the lips of the seals for damage or warpage. Replace if necessary.

5-2. Rear Wheel




Fig. 5-2-1 Rear Wheel Components

1. Removal

- 1) Remove the tension bar (anchor bar) and brake rod from the rear brake shoe plate. (Figs. 5-2-2, 3 and 4)




Fig. 5-2-2




Fig. 5-2-3




Fig. 5-2-4

- 2) Remove the rear wheel shaft nut, and pull out the shaft. (Figs. 5-2-5 and 6)




Fig. 5-2-5




Fig. 5-2-6

- 3) Remove the distance collar. (Fig. 5-2-7)
- 4) Remove the rear wheel ass'y (Fig. 5-2-8)




Fig. 5-2-7



Fig. 5-2-8

2. Checking and Adjustment

1) Runout of the Rim

Check the rim in the same manner as in the case of the front wheel. Runout limits-2 mm or less.

2) Brake Shoe

Check the brake shoe in the same manner as in the case of the front wheel.

3) Brake Drum

Check the brake in the same manner as in the case of the front wheel.

4) Repairing the Brake Shoe

Repair the brake shoe in the same manner as in the case of the front wheel.

5-3. Replacing Tires

1) Removal

- a. Remove the valve cap and lock nut from the tire valve, and deflate the tire.
- b. Remove the tire from the wheel rim by the use of two tire levers. (Exercise care to avoid damaging the inner tube with the levers.)

2) Installation

- a. Replace the tube between the tire and the wheel rim, and inflate the tube half. Be sure that the valve stem is directed toward the wheel shaft.
- b. Mount the tire on the wheel rim by the use of tire levers. For this operation, it is advisable that the bead on one side of the tire be pushed in toward the rim flange.
- c. To avoid pinching the tube between the tire and the rim, tap the tire with a hammer.
- d. Tighten the tire valve lock nut, and inflate the tire to the recommended pressure then install the valve cap.




Fig. 5-3-1

5-4. Rear Sprocket Wheel

1. Removal

- 1) Disconnect the chain joint and remove the chain. (Fig. 5-4-1)




Fig. 5-4-1

- 2) Remove the sprocket shaft nut, then the sprocket. (Fig. 5-4-2)




Fig. 5-4-2

www.legends-yamaha-enduros.com

2. Checking and Adjustment

The rear sprocket wheel is installed on the clutch hub. To replace the sprocket, take the following steps. (Fig. 5-4-3)

- 1) Remove the sprocket.
 - a. Flatten the lock washer.
- b. Remove the sprocket mounting bolts. (Fig. 5-4-4)




Fig. 5-4-3




Fig. 5-4-4

2) Cheking

Check the lock washers and hexagonal bolts for breakage and damage. If the sprocket wheel lock washer is damaged or not bent to lock the hexagonal bolt, the bolt may come loose while travelling, and cause an accident. Therefore, the bolt should be fully tightened and secured by the lock washer.

The sprocket wheel should be checked for wear in the same manner as in the case of the drive sprocket.




Fig. 5-4-5

5-5. Rear Arm

1. Checking

Check the play of the rear arm by shaking it as shown in Fig. 5-5-1, with the rear arm installed.

If the play is excessive, replace the rear arm bushing or the rear arm shaft, whichever shows the wear.

Insert the bushing into the rear arm, then onto the rear arm shaft, and check it for play. If the play is excessive, replace the bushing. Grease the rear arm shaft from time to time.



Fig. 5-5-1

REPLACING REAR SWING ARM BUSHINGS

On motorcycles being habitually used for on-the-street riding, rear swing arm bushings should be replaced every 10,000 km (6,000 miles.)

The same may not apply to those used for racing or rough riding. Replacement should be made according to machine condition such as excessive play of the rear swing arm, or hard steering, (wander, shimmy, or rear wheel hop, or upon request of the customer.)

5-6. Fuel Tank

1. Removal

- 1) Drain the fuel
- 2) Disconnect the cross over pipe.
- 3) Remove the seat.




Fig. 5-6-1

- 4) Remove the tank mounting bolt.
(Fig. 5-6-1)
- 5) Raise the rear of the tank and slide it rearward then lift it off the machine.
(Fig. 5-6-2)



Fig. 5-6-2

5-7. Front Fork

1. Removal

- 1) Remove the front fender, and remove the inner tube cap bolt.
- 2) Loosen the inner tube clamping bolt on the underbracket. (Fig. 5-7-1)
- 3) Draw the outer tube downward to remove the assembly. (Fig. 5-7-2)



Fig. 5-7-1




Fig. 5-7-2

2. Disassembling the Outer and inner Tubes

- a. Wind a rubber sheet or a tire tube around the outer tube nut, and remove the nut. Disassemble the tubes in the manner as shown in Figs. 5-7-3 or 4.




Fig. 5-7-3




Fig. 5-7-4

3. Checking

1) Inner Tube

Check the inner tube for any bend or scratches. A minor bend may be corrected, but replacement is preferred.

2) Oil Seal

When disassembling the front fork, be sure to replace the oil seal, and "O" ring.




Fig. 5-7-5

4. Reassembling

1) Reassembling the Front Fork (without mounting on the chassis)

To reassemble the front fork, reverse the sequence of disassembling as mentioned above.

After reassembling, check to see if the inner tube slides smoothly. amaha-enduros.com
(Fig. 5-7-6)




Fig. 5-7-6

2) Mounting the Front Fork on the Chassis

- a. Pull the front fork upward by using the front fork puller, and tighten the underbracket clamping bolt.

(Fig. 5-7-7)



Fig. 5-7-7

- b. Fill the inner tube with the specified front fork oil, pouring through the top end opening of the tube.

(Fig. 5-7-8)

Oil amount $147 \frac{+10}{-5}$ cc (5.0 fl-oz.)
each side.

Oil

Mobile oil #30.....	80%	}
Spindle oil #60	20%	

Use a 4:1 mixture

YAMAHA gear oil or Motor oil SAE 10W/30

- c. Install the inner tube cap bolt, and tighten it. (Fig. 5-7-9)



Fig. 5-7-8




Fig. 5-7-9

www.legends-yamaha-enduros.com

5-8. Rear Cushion

The rear cushion is not designed to be disassembled, so this paragraph discusses how to check for oil leakages.

1. Checking Method of Oil Leakages

When checking the rear cushion, you may often find oil seepage on the lower part of the outer cover. In most cases, however, this results from melting of the grease applied to the spring inside, and this will not impair the function of the rear cushion.

Take the following steps to inspect for cushion oil leakages.

- 1) Remove the rear cushion, and repeatedly depress the cushion a few times. If the spring quickly rebounds half-way, and slowly the last 10 mm, the cushion is in good working condition. If the spring quickly rebounds all the way, the cushion must be leaky. Replace it with a new one.

(Fig. 5-8-1)




Fig. 5-8-1

CHAPTER 6. ELECTRICAL EQUIPMENT

6-1. General

The YAMAHA Sports 90HS1 employs an a.c. generator for its electrical system. The a.c. current produced is rectified by a single-phase, bridge silicon rectifier and supplied to the battery, ignition coils, head light, tail light, stop light, neutral pilot light, flasher light, flasher pilot and horn.

6-2. Main Component Parts

A. A.C. Generator

The A.C. generator is a sort of magneto generator, in which a six-pole magnet rotates in the stationary magnetic field inside the armature. Generator principles are similar to those of flywheel magnetos. Compared with conventional ignition and starting dynamos, the a.c. generator has the following advantages.

- 1) Simplified construction, durable and free of trouble.
- 2) Less number of parts requiring adjustments, such as regulators, and simple handling.

1. A.C. Generator Performance Curves




Fig. 6-2-1

2. Main Specifications of A.C. Generator

Item	Description
Maker	Hitach Ltd.
Model	K108-08
Direction of rotation and R.P.M	Left, 300-9,500 r.p.m.
Voltage	12V
Normal load	Battery 12-V, 5.5AH+2 ignition coils
Night-time load	Normal load+head light, Head lamp (12V, 35W) +tail light (12V, 7W) +meter light (12V, 3W×2)
Charging performance	
Day time	At the begining of charging: Under 1,900 r.p.m. 1.3±0.5A/5,000r.p.m, at battery 16.4V 2.0±0.7A/8,000r.p.m, at battery 16.6V
Night time	1.2±0.5A/5,000r.p.m, at battery 16.2V 1.7±0.7A/8,000r.p.m, at battery 16.4V
Breaker point gap	0.3-0.35mm (0.012~0.014")
Condenser capacitance	0.22±10%μF
Ignition timing	1.8±0.15mm. B.T.D.C.

3. Inspecting the A.C. Generator

When the head light is not bright or when the battery is quickly discharged, check the following points.

1) Measuring the Generated Voltage (No-load Voltage)

- a. Disconnect three lead wires, yellow, green and white, from the wire harness which is connected to the generator.
- b. Connect tester leads (a. c. 100V) to the terminals as shown in Fig. 6-2-2 (day-time) and in Fig. 6-2-3 (night-time).
- c. Start the engine, and measure voltage at specific speeds, with the main switch both for day and night time.




Fig. 6-2-2 Day time no-load voltage




Fig. 6-2-3 Night time no-load voltage

Standard Value:

R. P. M.	Day Time	Night Time
3,000 r.p.m.	Approx. 48—58V	Same as left
5,000 r.p.m.	Approx. 83—97V	"

2) Measuring the Charging Current




Fig. 6-2-4 Measuring the charging current

- Disconnect the battery's red lead wire connector.
- Connect the tester lead wires (D.C. ammeter, 5 A) to the connector as shown in Fig. 6-2-4.
- Start the engine, and measure the charging current at specific speeds, with the switch both for day and night time.

Note: If the battery is in a low state of charge, the charging rate will be found high.

Standard Value:

Engine R. P. M.	Day Time	Night Time
5,000 r.p.m.	$1.3 \pm 0.5A$ (Battery 16.4V)	$1.5 \pm 0.5A$ (Battery 16.2V)
8,000 r.p.m.	$2.0 \pm 0.7A$ (16.6V)	$2.0 \pm 0.7A$ (16.4A)

3) Measuring the Output Current.




Fig. 6-2-5 Measuring the Output Current

- a. Connect a tester (D.C. ammeter, 10 A) to the battery as shown in Fig. 6-2-5, and measure the current at specific engine r.p.m., with the switch both for day and night.

Standard Value:

Engine R.P.M	Day Time	Night Time
3,000r.p.m.	$2.8 \pm 0.5A$	$6.7 \pm 0.5A$
5,000r.p.m.	$3.2 \pm 0.5A$	$7.1 \pm 0.5A$

B. Ignition Coil

The ignition coil is a transformer with approximately 50 times as many windings in the secondary coil as in the primary. If the electric current supplied to the primary coil (from the battery) is interrupted by a contact breaker, the primary coil will produce a 150-300 volts current surge by self-induction. This current is boosted to 7,000-10,000 volts by the mutual induction of the larger number of secondary coil windings, thus making a spark jump across the gap between the spark plug electrodes.




Fig. 6-2-6
www.legends-yamaha-enthusiasts.com

Note: The type of the ignition coil is similar to that as used in “dynamo-equipped” motor cycles.

1. Specifications of the Ignition Coil

Item	Description	Remarks
Maker	Hitachi Ltd.	
Model	C11	
Spark performance	Battery 8V, 1000r.p.m. 6mm or more Battery 14V, 7,000r.p.m. 7mm or more	
Primary coil resistance	4.2Ω—5.2Ω at 20°C	
Secondary coil resistance	5KΩ—8KΩ	
Insulation resistance	10MΩ or more at 20°C	(Between primary coil terminals and case)

2. Inspection

If no sparks are produced at all or if sparks are weak, check the ignition coil and contact breaker.

- 1) Checking the Ignition Coil (after removed)
Use a 12-V battery for testing the ignition coil disconnected from the engine.

If the tester reads a spark of more than 7 mm, the ignition coil is in good condition.

- 2) Checking the Ignition Coil as Installed (Practical test)




Fig. 6-2-7




Fig. 6-2-8

- Disconnect the leads from the a.c. generator's terminal I, and connect the leads to the tester's primary and secondary (-) sides.
- Disconnect the high-tension lead from the spark plug cap, and install an adaptor (copper or steel wire) on the plug cap. Then, connect the adaptor to the tester's secondary side (+).
- Connect the tester's primary (+) side to the horn terminal (brown lead).
- Use a 12-V battery as a power source for the tester.

Note: The ignition coil can be checked by measuring the resistance value on the primary and secondary sides.

C. Silicon Rectifiers

The silicon rectifier converts the alternating current produced by the a.c. generator into a direct current, and its circuits are a singlephase, bridge type.



Fig. 6-2-9

1. Rectifier Connection Diagram




Fig. 6-2-10

2. Simplified Measurement of Silicon Diodes (See Fig. 6-2-10.)

- To check diode 1, connect the green lead and shaft with tester's (ohmmeter) resistance measuring terminals (+) and (-), alternately changing connections. (For instance, connect the (+) terminal of the tester to the shaft, and the terminal to the green lead, then test the current flow. Next, change these connections, and test the current flow. If the current is found to flow through either one of these connections, diode is considered to be in good condition. If the current flows through both connections, the diode is in short-circuit. If no current flows through both connections, the diode is “burnt out.”)
- To check diode 2, connect the red lead and green lead in the same manner as mentioned in a. above, and check.
- To check diode 3, connect the white lead and shaft in the same manner as mentioned in a. above, and check.
- To check diode 4, connect the red lead and white lead in the same manner as mentioned in a. above, and check.

D. Battery

The battery is Furukawa Battery's BST3-12D or G.S.'s MG3-12E. (Both are a 12-volt, 5.5 A.H. battery). It is the same type of battery as used for the YL1, YL2, YR1 and YM2. The specific gravity is 1.280@ 20° c.

E. Other Parts

Name of Parts	Rating	Remarks
Head light	12V, 25W/25W	MF-12
Tail/stop light	12V, 7/23W 12V, 7/23W	
Speedometer	Illumination light, 12V, 3W	
	Flasher pilot light, 12V, 3W	
	Neutral light, 12V, 3W	
Horn	12V, 1.5A	
Spark plug	B-9HC	

www.legends-yamaha-enduros.com

6-3. Caution on Handling Electrical Equipment

1. Never disconnect the battery from the circuit while the engine is running.

Otherwise, the no-load voltage (400V/9,000 rpm) from the a.c. generator and a surge of voltage from the ignition coil will break the silicon diodes. Any burnt-out fuse or any loosened or disconnected connector of the battery circuit will result in silicon diode breakage as well. The silicon rectifier is ground to the shaft. Therefore, take special care when installing it on the mounting plate and installing the mounting plate on the chassis.

2. Never connect the battery in the wrong way.

Wrong connections of battery terminals will result in the short-circuit of the battery through the rectifier, thus causing a large amount of current to flow to the silicon rectifier and damaging it.

3. Always apply correct loads.

Use the loads as specified for the a.c. generator charging performance, so that the battery will be charged correctly.

The larger load will decrease the charging current, while the smaller load will increase the charging current, thus causing the battery to be easily discharged or overcharged.

4. Checking the battery fluid level

Charging by the a.c. generator is a sort of constant-current charging system. Compared with the starter dynamo or ignition dynamo employing the constant-voltage charging system, battery fluid consumption will be greater. Check the battery fluid level from time to time.

5. Handling the silicon rectifier

Never connect the circuit in the wrong way, nor expose the silicon rectifier to high temperatures. It will endure 140°C at maximum (at the junction).


Temperatures higher than that will impair the rectifier.

When testing the rectifier, keep it from high voltage (crest value 400V or more) and from a large amount of current (rating 8.5A or more).

M E M O

www.legendary-yamaha-endurance.com

Circuit Diagram



www.legends-yamaha-enduros.com



YAMAHA MOTOR CO., LTD.

PRINTED IN JAPAN