

www.legends-yamaha-enduros.com

MOTORCYCLE

FOREWORD

The Yamaha 125 AT1 is originally designed for off-the-road riding as a trials machine or a scrambler, but it is also built to excel in high speed performance over the road or highways.

Not only that, it is equipped with the safety parts required for a street touring model. Another attractive feature is its ready convertibility to a high-power motocrosser with tuning parts. (The AT1M is equipped with the GYT parts as standard equipment.)

This manual is offered so that all Yamaha dealers and service engineers will become familiar with the technical information and service instructions essential to the AT1.

YAMAHA MOTOR CO., LTD. SERVICE DIVISION

uamaha-endura

Contents

Chapter I General 5
I-1 Features
I - 2 Profile
I - 3 Specifications
I – 4 Performance Curves10
I $-$ 5 Tools and Instruments for Shop Service
Chapter II Yamaha Autolube14
II — 1 What is Yamaha Autolube?14
II – 2 Features of Yamaha Autolube14
II — 3 Handling the Oil Pump15
Chapter III 5-Port Cylinder Induction System
III-1 Description of 5-Port Cylinder Induction System20
III- 2 Construction and Features Design of the 5-port Induction System 20
Chapter IV Engine
IV— 1 Engine Removal·····22
IV— 2 Cylinder Head······26
IV- 3 Cylinder
IV- 4 Piston Pin ·····29
IV- 5 Piston Ring30
IV- 6 Piston
IV-7-1 Flywheel Magneto
IV-7-2 Starter Dynamo
IV- 8 Crankcase Cover (R.H.)
IV- 9 Clutch
IV-10 Primary Drive Gear43
IV-11 Kick Starter Mechanism
IV-12 Shift Mechanism47
IV-13 Drive Sprocket49

IV-14 Crank Case51
IV-15 Transmission Assembly52
IV-16 Crank Shaft
IV-17 Bearings and Oil Seals59
IV-18 Carburetor60
IV-19 Air Cleaner64
Chapter V Chassis
V-1 Front Wheel65
V- 2 Rear Whee]70
V- 3 Rear Wheel Sprocket75
V- 4 Tires and Tubes
V- 5 Front Forks
V— 6 Rear Shocks
V- 7 Gas Tank
V- 8 Rear Swing Arm83
V- 9 Steering Head85
V-10 Oil Tank, Battery Box and Tool Box86
V-11 Frame:86
V-12 Handlebars
V-13 Miscellaneous
Chapter VI Electrical System for ATI& ATIM
VI- 1 Description
VI- 2 Table of Component Parts
VI- 3 Connection Diagram
VI- 4 Ignition System-Functin and Service
VI- 5 Ignition Timing88
VI- 6 Ignition Coil
VI- 7 Condenser·····89
VI- 8 Charging System90
VI- 9 Battery
VI-10 Checking the Main Switch94
VI-11 Spark Plug94
VI-12 Lighting and Signal Systems95


Chapter VII Electrical System for AT1
VII-1 Description97
VII- 2 Table of Component parts97
VII- 3 Main Components
VII- 4 Connection Diagram
VII- 5 Starter Dynamo
VII- 6 Regulator
VII- 7 Ignition Coil 109
Chapter VIII Conversion of the YAMAHA AT1 for racing 111
VIII- 1 Engine Tune-up 111
VIII- 2 Modification of the chassis 112
VIII- 3 Service Data 113
VIII- 4 Change in Specifications
VIII— 5 Miscellaneous Notes

Chapter I General

I-1 Profile

www.commences.com









I-2 Features of Yamaha 125AT1

1. High-performance Single Cylinder Engine

The Yamaha 125 AT1 utilizes a powerful two-stroke 125 cc engine. The new five-port cylinder, which is another Yamaha technical development, greatly improves engine efficiency and is responsible for high power output throughout a broad RPM range.

2. Highly-dependable Yamaha Autolube

Yamaha Autolube provides superior engine lubrication that extends the life of the engine.

3. Easy Starting

The engine can be started by simply disengaging the clutch and kicking the kick pedal without shifting gears back to neutral. This is a valuable convenience to the rider. The AT1 also has an electric starter dynamo for easier starting. The AT1M is equipped with a magneto. To start the engine kick the kick pedal.

4. Powerful Brakes

Patented waterproof, dustproof brake drums provide safe, fade-free braking on wet or dusty roads.

5. Adjustable Rear Cushion

The rear cushions are adjustable for three positions. The rider can adjust spring tension to compensate for varying weight, speed, and road conditions.

6. Front Fork Design

The Yamaha 125 AT1 employs a front fork design well-known for its strength and superior handling characteristics. Its use assures the rider of the ultimate suspension for even the roughest terrain. The AT1M also employs an oil damper for better driving stability.

7. Speedometer and Tachometer

Both speedometer and tachometer are standard equipment. Individual units are separately mounted for maximum visibility. An additional feature of the speedometer is an odometer which can be reset to zero for trip or enduro purposes.

8. Tires

The YAMAHA AT1 is fitted with Dunlop Trials Universal as standard equipment. This particular tread is one of the most versatile available. It gives maximum trail traction and yet is compatible with road usage.

9. Carburetor Starter Feature

Yamaha's starter feature is already well-known for its easy starting. Equipped with this unique carburetor, the Yamaha AT1 is quick starting under all conditions.

10. GYT (Genuine Yamaha Tuning) Kit

The AT1M is furnished with the GYT kit so that it can be converted into a fully-equipped motocrosser.

Model:	YAMAHA 125 AT1	YAMAHA 125 AT1M
Dimensions:		
Overall length	77.2 in.	76.4 in.
Overall width	35.8 in	35.8 in.
Overall height	42.9 in.	43.1 in.
Wheelbase	50.6 in.	50.8 in.
Min. ground clearance	8.9 in.	9.1 in.
Weight: Net	218 lbs.	202 lbs.
Gross	234 lbs.	218 lbs.
Performance:	234 105.	218 105.
	60 1 1 -	20
Max. speed	60 mph plus	70 mph plus
Fuel consumption (on paved level roads)	141.1 mpg at 25 mph	
Climbing ability	30 degrees	
Min. turning radius	75.1 in.	74.8 in.
Braking distance	58.3 ft at 31 mph	58.3 ft at 31 mph
Engine:		
Model	AT1	Same as left
Туре	2 stroke, gasoline	Same as left
Lubricating system	Separate lubrication	YAMAHA Autolube & Gas/oil
	(YAMAHA Autolube)	mixture
Cylinder	Single, forward inclined, 5port	Same as left
Displacement	7.51 cu. in. (123 c.c.)	Same as left
Bore × Stroke	2.205 in.×1.969 in.	Same as left
Dore in Stroke	(56 mm×50 mm)	
Compression ratio	7.1:1	8.0:1
Max. power	11.5 BtP/7,500 r.p.m	18 BHP/8,500 r.p.m
	8.5 ft-lb/6,000 r.p.m	11.4 ft-lb/7,500 r.p.m
Max. torque	Electric & kick starter	Kick starter
Starting system		Magneto ignition
Ignition system	Battery ignition	
Carburetor:	111/01/011	Nu co cu
Туре	VM24SH	VM26SH
M. J.	#150	#240
J. N.	4D3-3 Stages	4D3-3 Stages
Air cleaner:	Wet, foam rubber	Same as left
Transmission:		
Clutch	Wet, multiple-disk	Same as left
Primary reduction system	Gear	Same as left
Primary reduction ratio	3.894 (74/19)	Same as left

I-3 Specifications & Performance Model AT1 & AT1M


- 8 -

Gear box:		
Туре	Constant mesh, 5-speed forward	Same as left
Reduction ratio 1st	3.182 (35/11)	Same as left
2nd	2.000 (30/15)	Same as left
3rd	1.368 (26/19)	
4th	1.000 (23/23)	Same as left
		Same as left
5 th	0.800 (20/25)	Same as left
Secondary reduction system	Chain	Same as left
Secondary reduction ratio	3.214 (45/14)	3.267 (49/15)
Chassis:		
Frame	Tubular-Double loop	Same as left
Suspension system, front	Telescopic fork	Same as left
Suspension system, rear	Swinging, arm	Same as left
Cushion system, front	Coil spring, oil damper	Same as left
Cushion system, rear		
Susmon System, rear	Coil spring, oil damper	Same as left
Steering system:		
Steering angle	49° both right and left	Same as left
Caster	60.5°	Same as left
Trail	4.72 in. (120 mm)	4.84 in. (123 mm)
Braking system:		
Type of brake	Internal expansion	Same as left
Operation system, front	Right hand operation	Same as left
Operation system, rear	Right foot operation	Same as left
Tire size:		
Front	3.00-18-4PR	3.25-18-4PR
Rear	3.25-18-4PR	3.50-18-4PR
Dynamo:		
Model	GS114	F130
Manufacturer	HITACHI Ltd.	Same as left
Battery:	10.7 00 (0.070 100)	
Model	12N7-3B (BRT3-12E)	
Manufacturer	FURUKAWA Battry.	
Capacity	12V 7AH	egends-yamaha=enduros.com
Lighting:		
Head light	12V 25WD	
Tail light	12V 7W	
Stop light	12V 23W	
	$12V$ $3W \times 2$	
Meter light		
Flasher light	12V 1.5W	
High beam indicator light	12 V 1.5 W	
Tanks:		
I dliks.		
Gasoline tank capacity	1.9 US gal	1.9 US gal


MAAAAAAAAAA

~

I-4 PERFORMANCE CURVES




125AT1 DRIVING PERFORMANCE CURVES



125AT1 ENGINE PERFORMANCE CURVES


~~~~~~

manananananananananana



#### 125AT1M ENGINE PERFORMANCE CURVES

#### 125AT1M DRIVING PERFORMANCE CURVES



### 1-5 Tools and Instruments for Shop Service

The following tools and instruments are required to service the ATL.

1. General Tools





Fig. 1-5-1

2. Special Tools and instruments




- 1) Clutch holding tool (for YA6, YL1 and YCS1E)
  - ol 6) Armiture
- Crankcase disassembling tool
  Crankshaft assembling tool
- 4) Flywheel magneto holding tool (ATIM)
- 5) Flywheel magneto puller (ATIM)
- 5) Armature puller bolt (10 mm screw)
- In addition, an electro-tester, tachometer (engine rpm meter) hydrometer, etc. will

be furnished

Fig. 1-5-2

#### 3. Other Tools

الوجلين والموجلين والوجلين والويعلو والوراجي والمورا




The use of a wooden box as shown in the above photo will facilitate engine service and overhaul. Consumable parts (such as gaskets) and replacement parts must also be on hand.

## Chapter II. YAMAHA Autolube (Automatic, Separate Lubricating System)

#### II-1. What is YAMAHA Autolube?

Conventional 2-stroke engines are lubricated by oil premixed in gasoline, but YAMAHA's Autolube furnishes an automatic, separate lubrication system. That is, the oil in a separate oil tank is automatically regulated by the oil pump and fed to the engine according to engine speed and load.





#### II-2. Features of YAMAHA Autolube

The oil pump is driven by the engine through a reduction gear, and is connected to the carburetor throttle cable, which in turn is controlled by the accelerator grip. The oil pump automatically regulates the volume of lubricating oil according to engine speed and throttle valve opening, thus pumping the optimum amount of oil for engine lubrication under any operating condition.

This "automatic, separate lubrication" does not merely eliminate disadvantages in

the conventional pre-mix system, but it fruther improves the performance and efficiency of 2-stroke designs by eliminating certain oil-starvation conditions which formerly existed.

- A) The Autolube feeds an optimum amount of lubricating oil to the engine under any operating condition, thus featuring:
  - Less oil consumption.
  - Less carbon accumulation.
  - Less exhaust smoke.
  - Improved lubricating efficiency.
- B) The Autolube simplifies fuel supply, thus featuring:
  - Using straight gasoline directly in the gas tank.
  - · Less fuel contamination.
- C) The Autolube improves the reliability of lubrication, thus eliminating:
  - Special care concerning oil/fuel mixing ratio.

#### II-3. Handling the Oil Pump

Sec. 1.

The oil pump is a precision-machined assembly. Make no attempt to disassemble it. When you remove the oil pump from the engine, protect it from dust, dirt, etc., and after reinstalling it, bleed and adjust the pump correctly. Proper handling will keep the pump free from trouble.

The oil pump is similar in both construction and operation to other Autolube systems. The only difference is the employment of a  $5.5 \neq$  plunger because of larger consumption of oil by a 125 c.c. single cylinder engine.

#### II-3-A. Checking Minimum Pump Stroke

#### 1) Checking

- a. Fully close the accelerator grip.
- b. Turn the oil pump starter plate in the direction of the arrow marked on the plate. Then measure the gap between the adjustment pulley and the adjustment plate. Keep the gap as wide as possible by observing it with the eye.





and the second second

c. Insert a feeler gauge (0.15 mm.) into the gap.

When the gap allows it to enter ...... Stroke is correct.

When the gap does not allow ...... Stroke is insufficient.




Fig. 11-3-2

#### 2) Adjustment

a. Remove the adjustment plate lock nut, and then remove the adjustment plate.




Fig. II-3-3

 Install a 0.1 mm. adjustment shim where the adjustment plate was.



Fig. 11-3-4

c. Reinstall the adjustment plate lock nut, and measure minimum stroke. When the gap allows a 0.20 mm. feeler gauge to enter but does not allow a 0.25 mm, the stroke is correctly adjusted.


Minimum stroke adjustment standards.....0.20 to 0.25 mm.

#### II-3-B. Pump and Carburetor Setting

Follow the preceeding steps to check minimum stroke, and adjust it if incorrect. Then adjust the pump and carburetor as described in the steps below.


#### 1) Checking

a. Adjust the carburetor with the engine at idle, and remove all but 1 mm of slack from throttle cable B.






- To bring the play of the throttle cable into correct adjustment, loosen or tighten the throttle cable adjustment screw.
- To check this adjustment, lightly pull throttle cable B, and engine speed should slightly increase from idling r.p.m.
- b. Next, adjust throttle cable A so that the gap as shown in Fig. II-3-6 below will be between 0.5 and 1.0 mm.  $(0.02\sim0.04 \text{ in.})$



• Check the play of the throttle cable A by pulling the outer part of the throttle grip. If the play is excessive or insufficent, adjust the play with

the adjustment screw.

- c. Adjust the pump cable so that the marking (arrow) on the adjustment pulley is aligned with the guide pin.
  - Fully close the accelerator grip, and slowly turn it back until all the play has been taken out of throttle cable A. (When throttle cable A has a play of 0.5 to 1.0 mm, the accelerator grip will turn lightly. On the other hand, when the cable has no play at all, the accelerator grip will be somewhat tight.) Next, adjust the pump cable so that the marking on the adjustment pulley will be aligned with the guide pin.



#### II-3-C Bleeding

When the pump has been removed or the Autolube oil has run out, air will enter the pump. The air will cause an irregular flow of oil after the pump is mounted again or the oil is refilled. In order to prevent such an irregular flow of oil, bleed the pump in the following manner.

1) Remove the bleeder bolt.




Fig. II-3-9

- 18 -

2. Next, rotate the starter plate in the direction of the arrow marked on the plate. Continue turning the plate until no air comes ont with the oil and tighten the bleeder bolt. To facilitate this bleeding, fully open the accelerator grip and rotate the starter plate. As the plunger stroke becomes greater, the air can be quickly bled.



Fig. II-3-10

#### Chapter III 5-Port Cylinder Induction System

#### III-1 Description of 5-Port Cylinder Induction System.

The schnuerle loop scavenging system is the most commonly used induction system for the two-stroke engines. In the schnuerle loop system, two transfer ports on the right and left sides of the cylinder are employed to transfer 2 streams of fresh fuel in the loop design. This has proved to be the most effective induction system until the innovation of Yamaha's five-port cylinder. This conventional schnuerle loop system had a design limit in that the transfer ports could not be made large enough to completely clear the combustion chamber of exhaust gases because of the position of the intake and exhaust ports. This would result in a portion of exhaust gas remaining in the central area of the combustion chamber that would contaminate the fresh fuel charge.

The rotary valve induction system incorporates the use of a 3rd transfer port at the back of the cylinder that directs a fresh fuel charge to the dead area containing the remaining exhaust gases. But to incorporate the rotary valve system into the 125 c.c. single engine would result in physical design limitations of the engine. The physical limitations of excessive engine width and unattractive appearance restricts such an engine design.

Yamaha's Research and Engineering Departments, therefore, designed and perfected the five-port cylinder induction system that is used on the AT1 and AT1M. This new five-port system, with the incorporation of two additional specially designed transfer ports, completely removes all the exhaust gases previously left in the dead area of the cylinder.

Engine performance is greatly increased with the use of this five-port system.

#### III-2 Construction and Design of the 5-port Induction System

The 2 additional transfer passages are placed to the immediate rear of the standard transfer ports. These two additional ports run from the bottom of the cylinder up to the same height as the standard transfer ports. These additional ports are designed to direct the fresh charge at the area containing the remaining exhaust gases. As the fresh fuel charge enters the combustion area, the remaining exhaust gas is forced out the exhaust port, thus leaving the combustion area with an uncontaminated, full, fresh fuel charge. Therefore, these additional transfer ports perform with equivalent efficiency the task so well done by the additional third port of the rotary valve induction system. This assures constant and equal performance, both at low engine speeds and high engine speeds.




Fig. IV-2-1

This chapter describes the disassembly and reassembly of the engine, its removal from the chassis, and the necessary service data. However, except when overhauling the crankshaft assembly, transmission, shifter mechanism, or bearings and oil seals in the crankcase, it is suggested that engine be serviced without removing it from the chassis. This will save a lot of time and labor.

#### Preparation for disassembly of the engine:

- 1) All dirt, mud, dust, and foreign material should be thoroughly removed from the exterior of the engine assembly before removal and disassembly. This will prevent any harmful foreign material from entering the interior of the engine assembly.
- 2) Before engine removal and disassembly, be sure you have proper tools and cleaning equipment so you can perform a clean and efficient job.
- 3) During disassembly of the engine, clean all parts and place them in trays in order of disassembly. This will make assembly time faster and easier, and insure correct installation of all engine parts.

#### IV-1 Engine Removal

1. Start the engine and warm it up for a few minutes, then turn off the engine and drain the transmission oil. (Fig. IV-1-1)

#### Volume of sil: 700~800 c.c. (0.74~0.85 USqt.) (SAE10W/30)

- 2. Remove the muffler.
  - Remove the two springs and two bolts. (Figs. IV-1-2 and 3)
  - 2) Remove the muffler holding bolts. (Fig. IV-1-4)



Fig. IV-1-1




Fig. IV-1-2







Fig. IV-1-4




Fig. IV-1-5



4. Remove the lefthand crankcase cover.

3. Remove the change pedal.



- 5. On the AT1, equipped with a dynamo, all wire leads should be removed from the stator terminals. On the AT1M, equipped with a flywheel magneto, the wiring should be disconnected from the wire harness center at its connector.
- Disconnect the master link and remove the chain.

Fig. IV-1-7



Fig. IV-1-8






When jointing, be sure the drive chain master link is facing in the correct direction. driving direction



After jointing, adjust the chain free play to 25 mm. (1 in.) up and down at the center of the lower section with the rear wheel on the ground.

7. Remove the pump cover and pump cable.



9. Remove the carburetor. Fig. IV-1-10



Fig. IV-1-12

 Disconnect the oil line and be sure to plug the hole to prevent oil from flowing out. 8. Remove the tachometer cable.

~~

Fig. IV-1-11





Fig. IV-1-13



Fig. IV-1-14



11. Disconnect the leads at the bottom of the fuel tank.

- 25 -

12. Remove the three engine mounting bolts.





13. Remove the engine from the frame.




Fig. IV-1-17




Fig. IV-1-18

#### IV-2 Cylinder Head

The cylinder head is bolted on the cylinder with special bolts.

#### A. Removing

Remove the four special nuts from the top of the cylinder head, then the head and head gasket. Reverse the sequence for reinstallation. Replace the gasket, if damaged. Cylinder head tightening torque is  $25.3 \sim 28.9$  ft-lbs.  $(3.5 \sim 4.0 \text{ kg-m})$ 



Fig. IV-2-1





Fig. IV-2-2

#### **B. Removing Carbon Deposits**

Carbon deposits inside the cylinder head combustion chamber and top of the piston will result in an increase in the compression ratio, as well as preignition and engine overheating. Scrape the cylinder head and piston dome clean.



#### IV-3 Cylinder


The Yamaha 125 AT1 engine employs an aluminum cylinder sleeved with special cast iron, that provides improved cooling effeciency and light weight. Like the DT1 engine, the cylinder is of 5-port design with superior scavenging efficiency.

\*The same type of cylinder is used on the ATIM, but for better performance, the cylinder's ports are laid out in a different way and are larger as compared with the AT1 standard.

#### A. Removing the Cylinder


 Remove the oil delivery line banjo bolt from cylinder.

 Remove the cylinder by striking it lightly with a plastic or rubber hammer.





 Always replace the cylinder base gasket when reassembling.



#### B. Checking the Cylinder for Wear

 Measure the amount of wear of the cylinder wall with a cylinder bore measuring micrometer or cylinder gauge. (Measure it at four depths while positioning the instrument at right angles to the crankshaft.) If the difference between the maximum and minimum diameter exceeds 0.05 mm (0.0019".), rebore and hone the cylinder.




Fig. IV-3-4

 The minimum clearance between the piston and the cylinder is 0.040-0.045 mm. (0.0016" and 0.0018")

#### C. Cylinder Reconditioning

1) Pistons are available in 0.25 and 0.50 mm. (0.010" and 0.020") oversizes.

- 2) The cylinder should be rebored and honed to the diameter of the oversize piston plus the minimum allowable clearance. (IV-3-B-2.)
- 3) The error between the maximum and minimum diameters after honing should be no more than 0.04 mm. (0.0015")

#### D. Removing Carbon Deposits

Scrape off the carbon accumulation in the exhaust port of the cylinder with a screwdriver.




Fig. IV-3-5

#### E. Installing the Cylinder

Put your fingers at each end of the piston ring, expand the ring, and slip it onto the piston. Align both ends of the ring with the knock pin in each ring groove. Next, insert the piston into the cylinder. Take care not to damage the bottom of the cylinder with the rings.



Fig. IV-3-6

#### IV-4 Piston Pin

#### A. Pulling out the Piston Pin

Remove the clips at both ends of the piston pin with needle nose pliers, and

press out the piston pin with a finger or a slot-head screw driver.

Note: Before removing the piston pin clips, cover the crankcase with a clean rag, so you will not accidentally drop the clip into the crankcase.




Fig. IV-4-1

#### **B.** Piston-to-Piston pin Fit

The piston pin should snugly fit in its bore so that it drags a little as you turn it. If the piston pin is loose, replace the pin and/or the piston.

If the pin has step-wear in its center, replace the needle bearing as well as the piston pin. Check the small end of the connecting rod for wear by inserting the piston pin.








#### **IV-5** Piston Ring

#### A. Removing the Piston Rings

Put your thumbs at each end of the piston ring and pull the piston ring ends apart. Remove the ring by moving the ring off the piston on the other side of the ring ends.







#### **B. Installing the Piston Ring**

First fit No. 2 ring over the piston, and then the No. 1 ring, and align their end gaps with the locating pin in each ring groove. (Fig. IV-5-3)

The printing on all rings must face up to position the gap properly at the pin.


#### C. Checking the Piston Rings

 Measuring piston ring wear Put the ring into the cylinder so that the ring is parallel to the cylinder bottom edge, and then measure the end gap with a feeler gauge (Fig. IV-5-4).

The end gap should be between 0.15 and 0.35 mm. (0.006''-0.014'') for both No. 1 and No. 2 rings.  $[0.4 \sim 0.6 \text{ mm.} (0.016'' \sim 0.024'')$  with GYT kitted.]

2) Removing carbon

Carbon on the piston rings and in the ring grooves will made the



rings stick in the piston, thus causing gas blow-by.

Remove the rings from the piston, and clean the carbon from the rings and ring grooves.


#### **IV-6** Piston

The piston is made of a high-silicon aluminum alloy. Both AT1 and AT1M employ the same type of piston, but the piston for the AT1M is modified for higher performance than the AT1 standard type piston.

#### A. Checking and Correcting the Piston to Cylinder Wall Clearance

1) Measuring piston clearance

Piston clearance is the difference between the minimum cylinder bore diameter and the maximum outside diameter of the piston. As described in IV-3 Cylinder, piston clearance should be 0.040-0.045 mm. (0.0016-0.0018 in.)



To determine the maximum piston diameter, measure the piston with a micrometer at right angles to the skirt 10 mm. (3/8 in.) from its bottom edge. (Fig. IV-6-1)

2) Checking and correcting scratches on the piston

A piston showing sign of seizure will result in noise and loss of engine power. It will also cause damage to the cylinder wall.

If a piston that has seized is used again without correction, another seizure will develop at the same area. Lightly sand the seizure



Fig. IV-6-2

"high spot" on the piston with #400 sandpaper until smooth. (Fig. IV-6-2)

- 3) Removing Carbon
  - Remove carbon accumulations on the piston head, using a screwdriver or a saw-blade. (Fig. IV-6-3)
- Carbon and gum accumlations in the piston groove will result in piston ring seizure. Remove them from the ring groove. (Fig. IV-6-4)



Fig. IV-6-3



Fig. IV-6-4

#### B. Piston Installation Direction

Install the piston with the arrow mark on the head pointing forward (toward the exhaust port of the cylinder).




Fig. IV-6-5


#### IV-7-1 Flyweel Magneto (AT1M)

A. Remove the nut using a flywheel magneto holding tool.




Fig. IV-7-1

B. Install the flywheel magneto puller. Turn it left and the flywheel magneto will break loose.





C. Remove the two screws holding the flywheel magneto base to the crankcase, and remove the flywheel magneto base.




D. Remove the woodruff key.

It is advisable to place the woodruff key on the flywheel magnets (using its magnetic force) while the key is removed for engine service.

#### IV-7-2 Starter Dynamo (AT1)


The AT1 is equipped with a starter dynamo for easy starting.

A. Remove the armature bolt, governor, and cam. (Fig. IV-7-4 and 5)



 B. Remove the yoke mounting bolts, and then the yoke assembly (Fig. IV-7-6)

C. Pull out the armature with the armature puller bolt or slide hammer. (Fig. IV-7-7).







Fig. IV-7-7



D. Remove the woodruff key. (Fig. IV-7-8) 1V-8 Crankcase Cover (R.II.)

# A. Removal

1) Remove the kick crank mounting bolt and the crank.





Fig. IV-8-1

2) Remove the pan head screws holding the crankcase cover, and then remove the case cover. (The cover can be removed without taking off the oil pump.)



 Remove the crankcase cover gasket. Replace it, if damaged.




Fig. IV-8-3

~~~~~

B. Installation

Spread YAMAHA Bond No.5 over the mating surface of the crankcase R. Place the crankcase cover gasket on the crankcase and apply Yamaha Bond No.5 and replace the crankcase cover R. Be sure to apply YAMAHA Bond No.5 to the mating sureface; otherwise, the crankcase will leak.

Note: When installing the crankcase cover(R), make sure that the pump drive gear (made from synthetic resin) is correctly engaged with the primary drive gear.




IV-9 Clutch

The clutch is a wet, multi-disc type, consisting of five molded cork friction plates and five clutch plates in the clutch housing that is mounted on the transmission main axle. To disengage the clutch, an inner push rod system is employed. The primary driven gear, coupled with the clutch housing, is meshed with a kick pinion gear. This allows the kick starter to be operated with the clutch disengaged or engaged.

A shock absorber consisting of rubbers is between the primary driven gear and the clutch housing.

The primary drive gear has 19 teeth, and the primary driven gear 74 teeth. (Primary reduction ratio......74/19=3.894)






Fig. IV-9-2 Clutch ass'y exploded view

A. Removing the Pressure Plate

Remove the five clutch spring holding screws, and take out the pressure plate and push crown.






Fig. IV-9-3



B. Removing the Clutch Boss

Fig. IV-9-4

Install the clutch holding tool (same as YA6, YL1, YCS1E) on the clutch boss. Loosen the lock nut, and then remove the cluch boss.



C. Checking the Clutch Spring

If the free length of the spring is 1 mm. (0.04 in.) or more shorter than the standard free length, replace it.



Free length 31.5 mm. (1.240 in.)

Fig. IV-9-7

D. Checking the Friction Plates

Inspect the friction plates for wear. Replace them if they show 0.4 mm. (0.157 in.) or more uneven contact.

Standard thickness 4.0 mm. (0.157 in.)




Fig. IV-9-8






E. Clutch Housing Assembly (integrated with the primary driven gear). There is a rubber friction ring placed on the outside of the clutch between the primary driven gear and the clutch housing in order to reduce gear noise at low engine speeds.

1) Inspection

Insert the primary gear retaining collar (spacer) in the primary driven gear boss and check it for radial play. If the play is excessive (allowable clearance is between 0.009~0.048mm.), replace the gear retaining collar because it will cause excessive noise.





If any scrathes are found, replace it so it will not impair clutch action.

F. Checking the Primary Gear Retaining Collar (Spacer)

Place the primary gear retaining collar around the main axle and again check it for radial play. If play exists (allowable clearance is between $0.020 \sim 0.062$ mm.), replace the gear retaining collar.

Replace any collar with step-wear on its outer surface.

G. Fitting Cushion Rings

A cushion ring is installed between the clutch boss and each of the friction plates to insure even engagement and complete disengagement of the plates. When fitting cushion rings, be sure they are flat and not twisted.



Fig. IV-9-11



Fig. IV-9-12

H. Checking the Push Rod

Remove the push rod and roll it over a surface plate. If the rod is bent, straighten or replace it.






Fig. IV-9-14

I. Caution on Re-assembling the Clutch

- *On both ends of the primary gear spacer are thrust washers and thrust bearings. If these washers and bearings are incorrectly installed, or omitted, the clutch boss will directly rub on the primary driven gear, impairing clutch action.
- * The thrust bearing assembly fits on the primary retaining collar, but it may slip out of place when installing clutch boss. Therefore, apply grease to both surfaces of the bearing to make it stick to the gear retaining collar.

Before fitting the clutch boss, install the clutch plates, friction plates, etc., and then install the clutch boss.



- 42 -

J. Adjusting the Clutch

1) Setting the Adjusting Screw Turn the adjusting screw in until it lightly seats against the push rod.

Next, back the screw off $\frac{1}{4}$ turn to get the proper spacing, then tighten the lock nut.

2) Adjusting the Clutch Cable Tension

The clutch cable becomes slackened after being used for a long time.

Adjust the cable so that the play at the clutch handle is from 2 to 3 mm. (1/16-1/8 in.)




Fig. IV-9-15




Fig. IV-9-16

IV-10 Primary Drive Gear

A. Removal

Feed a rolled-up rag between the teeth of the primary drive gear and the primary driven gear to lock them, and loosen the primary drive gear lock nut. The primary gear can then be forced off by using two screwdrivers, as shown in Fig. IV-10-2.





IV-11 Kick Starter Mechanism

The primary kick-starter system (one-touch kick-starter) is employed. However, a new "non-constant-mesh" mechanism has deen introduced into the AT1 kick-starter, instead of the constant-mesh kick gear type, such as the ratchet and roller-rock systems.

That is, the kick gear meshes with idler gear only when the kick starter pedal is kicked. After the engine is started, the kick gear is off the idler gear. This mechanism not only eliminates noise resulting from the constant mesh of the kick gear with the idler gear, but also greatly contributes to the durability of the kick starter assembly.





Fig. IV-11-1

- 44 -





A. Removal

N. P. P. P. P.

1) Remove the kick spring




Fig. IV-11-3






mana

2) Then remove the kick starter assembly


B. Removing the Kick Idler Gear

Remove the circlip with clip pliers, and then the kick idler gear can be easily removed.



C. Tachometer gear units

The tachometer-drive gear is engaged with the primary drive gear to convey the revolutions per minute of the crankshaft to the tachometer through the tachometer cable.




IV-12 Shift Mechanism

The AT1 shift mechanism is operated in five stages by a seasaw type change pedal. As the change pedal is depressed, gear shift arm B moves gear shift arm A, which in turn pushes on one of the gear shift pins attached to the gear shift drum, thereby turning the gear shift drum. A total of five gear shift pins are attached to the drum, and therefore, each time the change pedal is depressed, the drum rotates 1/5 of a revolution.

That is, one full turn of the gear shift drum is made in five stages; 1st, 2nd, 3rd, 4th and 5th.

Slotted guides are grooved in the shift drum, and the shift fork cam follower pins are placed in these slotted guides. Therefore, as the drum turns, the shift forks slide back and forth in the slotted guides. Shift fork 1 moves the 2nd and 3rd gears, shift fork 2 the 1st gear, and shift fork 3 moves the 4th and 5th gears. The neutral position is located between 1st and 2nd gears, and the neutral stopper mechanism is located on the left side of the shift drum.



- 47 -

A. Removing the Change Azle Assembly

 Remove the circlip and washer from the change axle (left side crank case).

2) Turn the engine over, right side

assembly.

up, and pull out the change shaft





Fig. IV-12-2



B. Checking the gear shift parts (Fig. 1V-12-4)

1) Checking the Gear Shift Return Spring.

A broken or fatigued gear shift return spring will impair the return action of the shifting mechanism.


Fig. IV-12-3



Fig. IV-12-4

2) A fatigued or broken gear shift arm spring will impair shifting action. Check it, and replace if it is faulty. C. Adjusting the gear shift arm

Adjusting or correcting the travel of the gear shift arm to prevent improper shifting progression (excess feed or insullicient feed of the gear shift arm) is accomplished by turning the gear shift return spring stop screw (eccentric bolt) in or out. (Fig. IV-12-5)



IV-13 Drive Sprocket

A. Removal

 Straighten the bent edge of the lock washer with a screwdriver.

2) Hold the drive sprocket with the




Fig. IV-13-1



Fig. IV-13-2

flywheel magneto holding tool, and remove the sprocket nut. If the flywheel magneto holding tool is not available, shift the transmission to low gear, and fit a monkey wrench on the sprocket nut. Then tap the handle of the wrench with a hammer and the shock will loosen the nut. Remove the distance collar with pliers. (When reinstalling distance collar, apply grease to the oil seal lip groove.)



B. Inspection

A worn drive sprocket will result in excessive chain noise, and shorter the life of the chain. Check the sprocket for worn teeth, and replace if they are worn.




Fig. IV-13-4

IV-14 Crankcase

A. Separating

1) Remove neutral stopper.




Fig. IV-14-1



Fig. IV-14-2

2) Remove the change shift drum stopper lever and stopper spring.





Fig. IV-14-3

3) Remove the pan head screws from the left crankcase.



Fig. IV-14-4

4) Install the crankcase separating tool on the right crankcase. Divide the crankcase while alternately tapping the main axle and the crankcase with plastic tip hammer (IV-14-5, IV-14-6).



Note: Fully tighten the bolts of the crankcase dividing tool, keeping the tool in a horizontal position.

The crankcase is designed to split into two halves, right and left. Only one drain plug is provided for both the transmission and clutch housings. Both housings can be drained at the same time by removing the drain plug.

B. Reassembling

When reassembling the crankcase, be sure to apply YAMAHA BOND No.5 to the mating surfaces of both halves.




Fig. IV-14-7

IV-15 Transmission Assembly

The constant mesh, wide ratio, 5-speed transmission makes it possible to fully utilize the steady performance of the engine throughout the entire speed range from low to high.

For layout of the transmission and related parts, refer to Fig. IV-15-1 and 2. The primary reduction ratio is 74/19=3.894. Therefore the total retuction radios will be; Primary reduction ratio× Transmission gear reduction× Secondary reduction ratio= Total reduction radio.

| Prin | nary Reduction Ratio | 74/19=3.894 | | | |
|------|---------------------------|--------------------------|--------|--|--|
| Seco | Secondary Reduction Ratio | | | | |
| | Transmission Gear | Total
Reduction Ratio | | | |
| | Reduction Ratio | | | | |
| | | AT1 | AT1M | | |
| lst | 35/11=3.182 | 39.833 | 40.482 | | |
| 2nd | 30/15 = 2.000 | 25.038 | 25.446 | | |
| 3rd | 26/19 = 1.368 | 17.131 | 17.410 | | |
| 4 th | 23/23 = 1.000 | 12.519 | 12.723 | | |
| 5th | 20/25 = 0.800 | 10.015 | 10.178 | | |

van

~~~~~~




Fig. IV-15-1

- 53 -




Fig. IV-15-2

#### A. Removal

 Pull out the two shift fork guide bars.





2) Remove both the transmission assembly and the shift forks from the crankcase, while tapping the drive shaft end with a plastic-tip hammer.



Fig. IV-15-4

 To remove the shift drum, remove the shift cam blind plug set screw on the left side of the crankcase, and remove the shift cam blind plug.

Then remove the circlip and washer from the shift drum, and the shift drum can be pulled out from the opposite side.



#### **B.** Reinstallation

Reinstall the transmission and shifter as a unit in the left crankcase half after they are sub-assembled. They can not be installed separately. The transmission unit must be in neutral during installation.




Fig. IV-15-8


The crankshaft requires the highest degree of accuracy in engineering and servicing of all the engine parts.

The crankshaft is also more susceptible to wear, and therefore, it must be handled with special care.

To increase the inertia force of the crank, the diameter of the left crankshaft is increased to 25 mm. (0.98 in.) the thickness of the flywheel to 23.5 mm. (0.93 in.) and its diameter to 87 mm. (3.43 in.)







## A. Removing the Crankshaft Assembly

Remove the crankshaft assembly with the crankcase separating tool. Note: Fully tighten the bolts of the crankcase dividing tool, and keep the tool in parallel with the crankcase surface.



Fig. IV-16-3

a a a a a a a a a a a a a a a a a a

#### **B.** Installing the Crankshaft Assembly

Install the crankshaft assembly by using the crankshaft setting tool and the crank fitting spacer.

Hold the connecting rod at top dead center with one hand while turning the handle of the setting tool with the other.

Note: 1) The crankshaft setting tool is same as those used for YL1(AT1) and DT1(AT1M).





Fig. IV-16-4


# C. Inspection and Servicing

1) Checking the crankshaft components

Check connecting rod axial play at small end (to deter- mine the amount of wear of crank pin and bearing at large end) Fig. IV-16-5)	Small end play should not exceed 2 mm. (0.078 in.)	If small end play exceeds 2 mm, disassemble the crank shaft, check connecting rod crank pin and large end bearing. Replace defective parts. Small end play after reassembly should be within 0.8-1.0 mm. (0.031~0.04 in.)
Check the connecting rod for axial play at large end. (Fig. IV-16-6)	one side and insert a feeler	If excessive axial play is present, (0.6 mm or more) disassemble the crankshaft and replace any worn parts.
Check accuracy of the crankshaft ass'y runout. (Misalignment of parts of the crankshaft) (Fig. IV-16-7)	Dial gauge readings should be within 0.03 mm. (0.0012 in.)	Correct any misalignment by tapping the flywheel with a brass hammer and by using a wedge.



# IV-17 Bearings and Oil Seals



and a second and a second

·nanananana

#### 1. Removal and Installation

- 1) Removal
- a. Pry the oil seals out of place
  with a slot head screwdriver.
  Always replace the oil seals
  when overhauling the engine.
- b. Drive out the bearing with a bearing tool.








Fig. IV-17-3

2) Installation

Install bearings and oil seals with their stamped manufacturer's marks or numerals facing outward. (In other words, the stamped letters must be on the exposed view side.)

When installing bearings, pack


them with grease.

IV-18 Carburetor

The standard AT1 is equipped with a VM24SH 24 mm. carburetor that is equipped with a built-in starter jet.

Note that the AT1M is equipped with VM26SH type carburetor for better performance.

The carburetor is bolted to a 20 mm. thick bakelite insulator that is located between the carburetor and cylinder. This insulator provides more than adequate heat insulation. The carburetor floats have been specially designed to keep the float level from fluctuating due to vibration or shock. The main jet is installed in such a manner to provide quick and easy replacement from the outside by merely removing the jet holder on the bottom left side of the carburetor float bowl.



#### A. Checking the Carburetor

1) Float


Remove the float and shake it to check if gasoline is inside. If fuel leaks into the float while the engine is running, the float chamber fuel level will rise and make the fuel mixture too rich. Replace the float if it is deformed or leaking.


2) Float valve

Replace the float valve if its seating end is worn with a step or if it is scratched. Check the float valve spring for fatigue. Depress the float valve with your finger, and make sure that it properly seats against the valve seat. If the float valve spring is weakened, fuel will overflow, flooding the float chamber while the gas is on.

3) Overflowing

If fuel overflows, check the carburetor as described in 1) and 2) above. If neither 1) nor 2) cures the overflowing, it may be caused by dirt or dust in the fuel preventing the float valve from seating properly. If any dirt or dust is found, clean the carburetor, petcock and gas tank.








4) Cleaning the carburetor

Fig. IV-18-2

Disassemble the carburetor, and wash all its parts in a suitable solvent.

Then blow all the parts off with compressed air. All jets and another delicate parts should be cleaned by blowing compressed air through them.



- 62 -

#### **B. Float Level Adjustment**

The carburetor float level is checked by the Yamaha factory during assembly and testing. But rough riding, worn needle valve, or bent float arm can cause the float level to fluctuate. If the float level raises, this will cause a rich fuel/air mixture that can cause poor performance and spark plug fouling. If the float level decreases, this can cause a lean fuel/air mixture that can result in engine damage. If the machine is subjected to continuous rough riding or many miles of travel, the float level should be checked and set regularly and in the following manner.




Fig. IV-18-5

- 1) Remove the float chamber body, and turn over the mixing body. Let the float arm rest on the needle valve without compressing the spring.
- 2) Then measure the distance from the top of the float to the float bowl gasket surface.

Standard measurement 25.5 mm

 When the distance measures less than the recommended distance, bend the tang up. If it is greater, bend the tang down. (with carburetor body up side down.)

#### C. Idle-speed Adjustment

The idle adjustment should be set exactly to factory specifications. First, turn the air screw completely in, then back it out  $1\frac{1}{2}$  turns (both AT1 and AT1M). Next, adjust the throttle stop so that the engine idles at 1200-1300 rpm.


	Abbreviation	Specifications	
Name of Parts		AT1	ATIM & GYT
Main jet	M. J	#150	#240
Needle jet	N. J	N - 8	0-2
Jet needle	J.N	4D3-3 stages	Same as left
Pilot jet	P. J	# 30	"
Starter jet	G.S	# 40	
Throttle valve cut away	C. A	2.0	1.5
Air screw setting	A. S	11/2	Same as left
Idling speed	-	1200-1300 грт	"
I dent. Mark		248 A 1	248M1

#### **D.** Carburetor Setting Table

#### IV-19 Air Cleaner

#### A. Removal

To remove the air filter, first remove two oil tank fitting bolts. Next, remove the air cleaner case cap fitting spring and air cleaner case cap. Then the element can be removed.



#### **B.** Cleaning

A wet type, foam-rubber element is employed instead of a dry type, paper filter. This foam-rubber element is impregnated with oil so that its dust collecting efficiency is much greater than the paper filter.

The element should be cleaned by shaking it in oil mixed gasoline.





Fig. IV-19-4


Thoroughly remove the gasoline from the element, and install in the cleaner case.

# Chapter V Chassis

The Yamaha AT1 has been designed for versatility and a combination of uses. It is equipped with all necessary street legal equipment to insure pleasurable road or street riding. This machine can be quickly converted to a competion machine and therefore has been engineered to have a minimum weight factor. Yet with the reduction in weight; rigidity, strength, and safety have been incorporated in the design of the frame to provide an unexcelled competition machine.

#### V-1 Front Wheel

The 18" front wheel is equipped standard with a 3.00-18" Trials Universal tire,




#### Construction

1. Hub 2. Spoke set 3. Rim 4. Front tire 5. Tube 6. Rim band 7. Bearing spacer Spacer flange 8 9 Bearing 10. Oil seal 11. Bearing 12. Circlip 13. Thrust washer 2 14. Meter clutch 15. Drive gear 16. Brake shoe plate 17. Shaft cam Cam shaft shim 18. 19. Oil seal 20. Brake shoe complete 21. Brake shoe return spring 22. Cam shaft lever 23. Bolt 24. Nut 25. Spring washer 26. Plane washer 27. Meter gear Thrust washer 1 28. 29. Bushing 30. Oil seal 31. O ring 32. Stop ring 33. Wheel shaft 34. Hub dust cover Wheel shaft collar 35. 36. Shaft nut 37. Spring washer 38. Bead spacer 39. Grease nipple

This tire gives the rider assurance of maximum performance and safety for both road riding and trail riding. The front wheel brake size is  $110 \text{ mm.} \times 25 \text{ mm.}$  (4.33×0.98 in.) A labyrinth seal is installed between the wheel hub and brake plate to provide a seal against dust and water.

#### A. Removal

1) Disconnect the brake cable at the front brake lever.






 Disconnect both the brake cable and speedometer cable from the front wheel hub plate.



Fig. V-1-3

 Loosen the front wheel axle lock bolt.



4) Remove the front wheel nut.




Fig. V-1-5

5) Pull out the front wheel axle by turning it.



Fig. V-1-6

 Raise the front of the machine and set it on a box. Then remove the wheel assembly.

anner




Fig. V-1-7

### B. Checking

1) Run out of the rim

As shown in Fig. V-1-8, measure the runout of the rim with a dial gauge. Run out limits: 2 mm. (0.07 in.) or less.



# 2) Brake shoe


Measure the outside diameter at the brake shoe with slide calipers. If it measures less than 104 mm. (4.09 in.), replace it. Smooth out a rough shoe surface with sandpaper or with a file.

3) Brake drum

Oil or scratches on the inner surface of the brake drum will impair braking performance or result in abnormal noises. Clean or smooth out the surface with a rag soaked in laquer thinner or with sandpaper.







 Check the spokes. If they are loose or bent, replace or tighten

loose or bent, replace or tighten them. If the machine is ridden in rough country often, or raced, the sporkes should be checked regularly.

- 5) Repairing the brake shoe If the brake shoe has uneven contact with the brake drum or scratches, smooth out the surface with sandpaper or hand file.
- If the tire is excessively worn, replace it.
- Regularly check the tires for damage.




## Fig. V-1-11

- If the bearings allow excessive play in the wheel or if it does not turn smoothly, replace the bearing.
- 9) Replace a bent or damaged front wheel axle.
- 10) If the tooth surface of the helical speedometer drive gear is excessively worn, replace it.
- 11) Check the lips of the seals for damage or warpage. Replace if necessary.

#### Replacing the Wheel Bearing

- a. First clean the outside of the wheel hub.
- b. Insert the bent end of the special tool (as shown in Fig. V-1-13) into the hole located in the center of the bearing spacer, and drive the spacer out from the hub by tapping the other end of the special tool with a hammer. (Both bearing spacer and space flange can easily be removed.)
- c. Then push out the bearing on the other side.
- d. To install the wheel bearing, reverse the above sequence. Be sure to grease the bearing before installation and use the bearing fitting tool (furnished by Yamaha.).




- 69 -

#### V-2 Rear Wheel

The rear wheel is 18-in. size, and the rear tire is the 3.25-18 Trials Universal. The leading trailing type brake is of the 130 mm.×28 mm. ( $5.12\times1.10$  in.) size. A labyrinth seal between the wheel hub and the brake plate is provided to prevent water and dust leakage. The brake tension bar is of link design to minimize the shifting of the brake cam lever position when the rear swing arm is moving up and down. The rear fender is steel, and rubber mounted on the frame. It is also wide enough to protect the engine unit from dust and water.


Note that the AT1M uses 3.50-18" trials universal tires.






# A. Removal

1) Remove the tension bar and brake rod from the rear shoe plate.





 Loosen the chain tension adjusting nuts and bolts on both right and left sides.




Fig. V-2-4

3) Remove the rear wheel shaft nut.




Fig. V-2-5

~~~~~~~~~~

 Pull out the rear wheel shaft by striking it with a plastic tip hammer.




Fig. V-2-6

5) Remove the right-hand chain adjuster and distance collar.





Fig. V-2-7

6) Remove the rear brake plate.



 Lean the machine to the left and remove the rear wheel assembly.



Fig. V-2-10

Replacing the Wheel Bearing

Replace the wheel bearing in the same way as the front wheel bearing.

Replacing Tires

1) Removal

- a. Remove the valve cap and lock nut (12 mm.) from the tire valve, and deflate the tire.
- b. Remove the tire from the wheel rim by the use of two tire levers. (Exercise care to avoid damaging the inner tube with the levers.)

It is noted that to remove the inner tube, one side of the tire should be pried out of the wheel rim.

2) Installation

a. Insert the tube between the tire and the wheel rim, and inflate the tube. Be sure that the valve stem is directed toward the wheel shaft. At this time the tire is still halfway off the rim.

www.www.www.www.www.

- b. Force the tire completely back on the wheel rim by the use of tire levers.
 For this operation, it is advisable that the bead on the other side of the tire be pushed in toward the rim flange.
- c. To avoid pinching the tube between the tire and the rim, tap the tire with a hammer as the tire is partially inflated.
- d. Tighten the tire valve lock nut, and inflate the tire to the recommended pressure, then install the valve cap.

B. Inspection

1) Run out of the rim

Check the rim for run out in the same way as the front wheel. Maximum limit of runout.....2 mm. (0.07 in.) or less.

2) Brake shoe

Check the brake shoe in the same way as the front wheel. Minimum limit124 mm. (4.9 in.)

3) Brake drum

Check the brake drum in the same way as the front wheel.

- The spokes are measured in the same way as the front wheel. A loose spoke should be tightened.
- 5) If the bearing has excessive play or it does not turn smoothly, replace it.
- 6) If the tire or the pattern is worn out, replace the tire.
- 7) If the lip of the oil seal is damaged or warped, replace it.



V-3 Rear Wheel Sprocket

A. Checking and Adjustment

The rear wheel sprocket is installed on the clutch hub. To replace the sprocket, take the following steps.

- 1) Removing the sprocket
 - a. Bend the lock washer ears flat.



Fig. V-3-3

b. Remove the sprocket mounting bolts.



Fig. V-3-4

2) Checking

Check the lock washer and hexagonal bolt for breakage and damage. If the lock washer is not bent over the hexagon bolt head, or is broken, or the bolt is loose, the sprocket can come loose. Make sure that both lock washers and the mounting bolts are tight.





V-4 Tires and Tubes

1) Normal tire pressure

Though tire pressure is the rider's choice, the standard tire pressure is as follows.

a. On-the-road riding

Front14 lbs./in². (1.0 kg./cm².)

Rear17 lbs./in². (1.2 kg./cm².)

When the tire pressure is reduced below the specified value because of some reason, the tire may slip around the rim.

To prevent this slipping of the tire, bead stoppers should be used.

V-5 Front Forks

The AT1 is equipped with competition designed telescopic double dampening front forks. These specially designed front forks provide excellent riding comfort along with handling superiority. The maximum stroke travel is almost 5.8 inches (145 mm.)

The combination of fork stability and long stroke travel provides safety and handling ease for the rider over even the roughest terrain. This front fork design also reduces weight, eases maintenance, and gives functional and attractive appearance. The simplicity and dependability of the front forks is provided by the installation of the fork spring inside of the fork tube.

The 250 DT1 front fork can be used for the AT1 without modification it.


A. Removal

1) Remove the front fender

The light-weight aluminum front fender is rubber-mounted.




 Remove the inner tube cap bolt. Loosening the arrow marked pinch bolt must be done before the cap bolt is loosened.





 Loosen the inner tube damping bolt on the uunderbracket.



4) Pull the outer tube downward






~~~~~~~~~~~~~~~~~~~~~~~

# B. Disassembling the Inner and Outer Tubes

-----

1) Drain the oil from the fork

- 2) Remove the special bolt (arrow marked) from the bottom of the outer tubes.
- Fig. V-5-5



- 3) Place a rubber sheet or tire tube around the outer tube nut, and clamp it with a vise.
  - Note: Take care not to deform the outer tube when clamping it with the vise.
- 4) Fit the front wheel shaft in the outer tube, and turn it counterclockwise. The inner tube can be separated from the outer.




Fig. V-5-7








Fig V 5-9 Front Fork Exploded View

----

#### C. Checking

1) Inner tube

Check the inner tube for bends or scratches. If the bend is slight, it can be corrected with a press. It is recommended, however, to replace the tube if possible.

2) Oil seal

When disassembling the front fork, replace the oil seal in the outer tube nut.

#### **D.** Assembling

- 1) When assembling the front fork, reverse the order of disassembly. Check if the inner tube slides in and out smoothly.
- 2) Installing the front fork on the frame
  - a. Bring up the front fork to the correct position and tighten the under bracket mounting bolt.




Fig. V-5-10

- b. Pour oil into the inner tube through the upper end opening. Front fork oil: Motor oil 10 W/30 145~160 cc (4.9~5.4 fl.oz.) per fork leg.
- c. Install the cap bolt.


### V-6 Rear Shocks

The rear shocks have a maximum stroke of 90 mm. (3.54 in.) The rear cushion features superb damping and 3-position adjustable springs, that allow the rider to adjust the rear shocks to suit any riding condition.

It is possible to use the DT1 rear cushions for the AT1 without modifying them.

#### A. Checking the Condition of the Damping Units.

1) Remove the rear shock assembly.





 Compress the shock by applying weight as shown in Fig. V-6-2, and release it.

If the shock quickly restores halfway and then slowly returns to the original position after it reaches 10 mm. (3/8 in.) before the original position, the rear shocks are in good condition.





But if the cushion returns quickly to the original position, check the cushion for oil leakage, and replace the assembly if it leaks.

#### V-7 Gas Tank

The front of the tank is held to the frame by a hook on the tank that slips over a pin, and the rear is held by rubber band. Tank capacity is 7.2 litres (1.9 u.s.gal)

## A. Removing

 Set the petcock lever at the "Stop" position and disconnect the fuel line at the petcock.



2) Open the seat.

4




Fig. V-7-2



Fig. V-7-3

4) Remove the gas tank.

1

~~~~~~~~

3) Remove the rubber band.





Fig. V-7-4

V-8 Rear Swing Arm

The rear swing arm is made of steel tube that improves the strength and torsional rigidity. The pivot employs permanently lubricated bearings.

A. Removing

 Remove the chain case mounting bolts.



 Remove the rear swing arm shaft nut, pull out the shaft, and remove the rear swing arm.





Fig. V-8-2

B. Checking

- Check the play of the rear swing arm by shaking it as shown in Fig. V-8-3, with the rear swing arm installed. If the play is excessive, replace the rear swing arm bushing or the rear swing arm shaft.
- 2) Insert the bushing as indicated in Fig. V-8-4, and check it for play. It the play is excessive, replace the bushing.





3) Grease the rear arm shaft periodically.

Replacing Rear Swing Arm Bushings

On motorcycles being used only for on-the-street riding, rear swing arm bushings should be replaced every 10,000 km. (6,000 miles). The same may not apply to those used for racing or rough riding. Replacement should be made according to machine condition such as excessive play of the rear swing arm, or hard steering (wander, shimmy or rear wheel hop,) or upon request of the customer.

V-9 Steering Head





B. Checking

1) Ball Races and Steel Balls

Check the ball races and steel balls for pitting or wear. Check them very carefully if the machine has been in long use. If they are worn or cracked, replace all of them, because defective ball races or steel balls adversely affect the maneuverability of the machine. Replace any ball race having scratches or streaks resulting from wear. Clean and grease the balls and races periodically. Note: Do not use a combination of new halls and used races or vice versa. If any of these are found defective, replace the whole ball and race assembly.

V-10 Oil Tank, Battery Box and Tool Box

The oil tank is located on the left side under the seat. It is designed to be as narrow as possible so that it will not contact the rider's lower limbs when he stands upright on the footrests. To fill the autolube oil tank, lift the seat and the tank cap will be exposed. Oil tank capacity.....1.2 litres. (1.3 u.s qts)

The battery box is located right under the seat.

And the air cleaner case is located under the fuel tank.

V-11 Frame

The double cradle-type frame is made of high tension steel tubes that provide strength, rigidity and light weight. Other dimensional features include high ground clearance, narrow width, long wheelbase and long suspension stroke. The engine is bolted to the frame at three positions. The caster is measured at 60.50°.




Fig. V-11-1

V-12 Handlebars

The upswept type longer handlebars are ideal for motocross events and are provided with deep-cut pattern grips to prevent hand slippage. The lever holder is provided with adjusting screws for clutch cable and brake cable free play.

The meter bracket is mounted on the ends of the handle crown, to carry the speedometer on its left side and the tachometer on its right side.

V-13 Miscellaneous

The footrest is made of a single steel tube extending under the lower part of the frame, and bolted to the frame. The engine guard is bolted to the frame to protect the entire crankcase.....covering from the exhaust system to the drain plug.

Chapter VI Electrical System for AT1 & AT1M


VI-1 Description

The AT1M employs a flywheel magneto for its ignition system, same as in the DT1. As the AT1M is designed exclusively for off-the road riding, it is equipped with the flywheel magneto and ignition coil only; lights, signals, battery, rectifier and switches are not mounted.

| VI-2 | Table | of | Component | Parts |
|------|-------|----|-----------|-------|
|------|-------|----|-----------|-------|

| Parts | Manufacturer | Model & Type | Remarks |
|--|---|---|--|
| Flywheel magneto
Spark plug | Hitachi Ltd.
NGK | F-130-02
B-9E(AT1M) | |
| Headlight
Speedometer
Tachometer
Handlebar Switch | Koito Mfg.
Nippon Seiki
Nippon Seiki
Asahi Denso | 6V 25WD
Neutral pilot light 6V 15W
Meter light 6V 3W
Meter light 6V 3W | is interchangeable with DT1 |
| Main switch
Ignition coil
Horn | Asahi Denso
Hitachi Ltd.
Nikko Kinzoku | CM61-50
MF-6 | Is interchangeable with DT1
Is interchangeable with DT1 |
| Battery
Rectifier
Fuse | Nippon Battery
Mitsubishi Elec.
Osachi Mfg. | MV1-6D
DS10HJ
10A×2 | Is interchangeable with DTL
Is interchangeable with DT1 |
| Stop switch | Asahi Denso. | | |
| Tail light | Koito Mfg. | 6V 20W/5W | |
| Flasher light
Flasher relay | Imasen Elec.
Showa Elec. | 6V8W×4
B-9 6V8W×2+3W | |

VI-3 Connection Diagram



non leaendernamaharenduzos, com

VI-4 Ignition System-Function and Service

1. Function

The ignition system consists of the components as shown in Fig. VI-4-1. As the flywheel rotates, the contact breaker points begin to open and close, alternately. This make-and-break operation develops an electromotive force in the ignition power source coil, and produces a voltage in the ignition coil primary windings. The ignition coil is a kind of transformer, with a 1:50 turn ratio of the primary to the secondary winding. The voltage (150-300 V) which is produced in the primary coil, is stepped up to 12,000-14,000 V by mutual-induction, and the electric spark jumps across the spark plug electrodes.




Fig. VI-4-1

VI-5 Ignition Timing

Remove the spark plug and screw the dial indicator holder into the plug hole. Next, insert the dial indicator into the holder. Bring the piston up to T. D. C. and set the zero on the dial face to line up exactly with the dial indicator needle. The crankshaft should then be turned backwards, so that the piston travels down past 2.0 mm B. T. D. C. and slowly brought back up to precisely 2.0 mm B. T. D. C. (This removes any slack in the gears). Adjust the points so that they are just beginning to open with the piston in this position. A low resistance point checker (100 Ohms ore less) should be used to determine the opening and closing of the ignition points.

Ignition Timing, 1.8 mm. B. T. D. C.

Maximum ignition point gap 0.3 to 0.4 mm. (0.012"-0.015")

VI-6 Ignition Coil

Primary coil resistance value4.9 $\Omega \pm 10\%$ (20°C or 68°F) Secondary coil resistance value11 K $\Omega \pm 10\%$ (20°C or 68°F) (For measuring methods, refer to Fig. VI-6-1)




Fig. VI-6-1

Note: When measuring the secondary coil resistance value, disconnect the plug cap. Otherwise, the resistance of the $5K\Omega$ noise suppressor incorporated in the plug will be added to the tester reading.

Spark Test:

Remove spark plug from cylinder head and reconnect the high voltage lead. Then hold the spark plug approximately 7 mm away from the head and see if it sparks as you crank the kickstarter.


If it sparks at 7 mm. or so, and has blue white color, the ignition coil should be considered to be in good condition.

VI-7 Condenser

The condenser instantly stores a static electric charge as the contact breaker points separate, and the energy stored in the condenser discharges instantly when the points are closed. If it were not for the condenser, an electric arc would jump across the separating contact points, causing them to burn.

Burned contact points greatly affect the flow of current in the primary winding of the ignition coil.

If the contact points show excessive wear, or the spark is weak (the ignition coil is in good condition), check the condenser.



Set the tester on the "MO" position.

Fig. VI-7-1

Insulation resistance tests should be conducted by connecting the tester as shown in Fig. VI-7-1. If the pointer swings fully and the reading is more than $3M\Omega$, the insulation is in good condition. If the insulation is faulty, the pointer will stay pointing at the uppermost reading, indicating very little resistance.

Note: After this measurement, the condenser should be discharged by connecting the positive and negative sides with a thick wire.

Capacity tests can be performed by simply setting the tester to the condenser capacity. The tester should be connected with the condenser in the same way as in the case of the insulation resistance test. Before this measurement, be sure to set the tester correctly.

If the reading is within 0.22 μ F \pm 10%, the condenser capacity is correct.

VI-8 Charging System

The charging system consists of the flywheel magneto (charging and lighting coils), rectifier, and battery.

1. Flywheel Magneto

As the flywheel rotates, an alternating current is generated in the charging and lighting coils and converted to a half-wave current by means of a silicon rectifier. This half-wave current is charges battery.

Charging Capacity (Daytime)

Green lead: Charging beings at 3,000 r.p.m.

2.0 A or less at 8,000 r.p.m.

White/Red: 4.0 A or less at 8,000 r.p.m.




Fig. VI-8-1

Lighting Capacity (Night time)

(With normal loads and normal wiring.)

5.8 V or more at 2,000 r.p.m.

8.5 V or less at 8,000 r.p.m.

* The charging and lighting capacity is obtained when the battery is fully charged. If the battery is in a low state of charge and low in voltage, the charging rate will be not exactly the same as above. However, it is desirable that the figures are as close as possible.

How to Increase Charging Capacity

The flywheel magneto's green lead wire is connected to the wire harness' green lead. But if the battery is in a low state of charge, connect the magneto's white /Red lead to the wire harness' green lead. This will increase the chargine rate.


2. Silicon Rectifier

The alternating current, which is generated by the flywheel magneto, is rectified and charged to the battery. For this rectification, a single-phase halfwave silicon rectifier is employed.

Characteristics: Rated output-4A,

Rate peak inverse withstand voltage 400 V

Polarity:



a. Checking the Silicon Rectifier

For measurements, an ohmmeter can be used.




Fig. VI-8-2

Checking with Normal Connection

Connect the tester's red lead (+) to the silicon rectifier's red terminal, and connect the tester's black lead (-) to the rectifier's white terminal.

Standard value: $9-10 \Omega$

If the tester's pointer will not swing back from the over scale, the rectifier is defective.

Checking with Reversal Connection

Connect the tester the other way round.

Standard value: If the pointer will not swing, the rectifier is in good condition. If the pointer swings, the rectifier is faulty.

3. Operational Nut

The silicon rectifier can be damaged if subjected to overcharging. Special care should be taken to avoid a short circuit and/or incorrect connection of the positive and negative leads at the battery. Never connect the rectifier directly to the battery to make a continuity check.

VI-9 Battery

The battery is a 6 volt-2 AH unit that is the power source for the horn and stoplight. Because of the fluctuating charging rate due to the differences in engine R.P.M.s, the battery will lose its charge if the horn and stoplight are excessively used. The charging of the battery begins at about 3,000 R.P.M. Therefore, it is recommended to sustain engine R.P.M.s at about 3,000 to 4,000 R.P.M. to keep the battery charged properly. If the horn and stoplight are used very often, the battery water should be checked regularly as continuous charging will dissipate the water. If the battery will not retain a charge (and the battery is in good condition) the white/Red wire of the flywheel magneto can be connected to the green wire of the wiring harness. This will increase the charging rate. But if the machine is ridden for long periods of time with this wiring connection, the battery can be overcharged and damaged.

1. Checking

- 1) If sulfation occurs on plates due to lack of the battery electrolyte, showing white accumulations, the battery should be replaced.
- 2) If the bottoms of the cells are filled with corrosive material falling off plates, the battery should be replaced.
- 3) If the battery shows the following defects, it should be replaced.

O The voltage will not rise to a specific value even after long hours charging.

ONo gassing occurs in any cell.

• The 6 V battery requires a charging current of more than 8.4 volts in order to supply a current at a rate of 1 amp. per hour for 10 hours.

2. Service Life

The service life of a battery is usually 2 to 3 years, but lack of care as described below will shorten the life of the battery.

- 1) Negligence in re-filling the battery with electrolyte.
- 2) Battery being left discharged.
- 3) Over-charging by rushing charge.
- 4) Freezing.
- 5) Feeding of water or sulfuric acid containing impurities when re-filling the battery.

3. Storage

- If any motorcycle is not used for a long time, remove the battery and have it stored by a battery service shop. The following instructions should de observed by shops equipped with chargers.
 - 1) Recharge the battery.
 - 2) Store the battery in a cool, dry place, and avoid temperatures below 0°C. (32°F)
 - 3) Recharge the battery before mounting it on the motorcycle.

4. Service Standards

Battery: MV1-6D (Nippon Battery)

| Battery Spec. | 6V-2AH | |
|---|--|----------------------|
| Electrolyte-Specific gravity and quantity | 1.26-1.27, 110 c.c. | At full charge |
| Initial charging current | 0.2 A for 25 hours | Brand new motorcycle |
| Charging current | 0.2 A for 13 hours
(Charge until specific gravity
reaches 1.26-1.27) | When discharged |
| Refilling of electrolyte | Distilled water up to the max.
level line. | Once a month |

VI-10 Checking the Main Switch (removed from the chassis)

Key "O" position (Off) Black↔Switch body Ground to switch body. Key "I" position Black Pocket tester (for day) Red Blue Green↔White 0 -White Black Red↔Brown Key "∏" position Brown Green (for night) Yellow Π (Switch on the tester and use an ohmmeter.) Yellow↔White Main switch White↔Blue Fig. VI-10-1

Red↔Brown

If the readings or the above six measurements are nearly 0 Ω , and no short-circuit is noticed between the terminals, as well as between the lead terminal and the switch body, the main switch is in good condition.

VI-11 Spark Plug

The life of a plug and its discoloring vary, according to the habits of the rider. At each periodic inspection, replace burned or fouled plugs with suitable ones determined by the color and condition of the bad plugs. One machine may be ridden only in urban areas at low speeds, whereas another may be ridden for hours at high speeds, so confirm what the present plugs indicate by asking the rider how long and how fast he rides, and recommend a hot, standard, or cold plug accordingly. It is actually economical to install new plugs every 3,000 km (2,000 miles) since it will tend to keep the engine in good condition and prevent excessive fuel consumption.

- 94 -


1. How to "read" spark plug (condition)

- a. Best...When the porcelain around the center electrode is a light tan color.
- b. If the electrodes and porcelain are black and some what oily, replace the plug with a hotter-type for low speed riding.
- c. If the porcelain is burned white and/or the electrodes are partially burned away, replace the plug with a colder-type for high speed riding.

2. Inspection

Instruct the rider to:

Inspect and clean the spark plug at least once a month or every 1,000 km. (500 miles) Clean the electrodes of carbon and adjust the electrode gap to 0.5-0.6 mm. (0.023 in.) Be sure to use standard B-8E (AT1M...B-9E) plug as replacements to avoid any error in reach.



VI-12 Lighting and Signal Systems

The lighting and signal systems consist of the horn and stop light (power sourcebattery) and the head light, tail light, meter lamps, flasher light, speedometer and tachometer (power source-flywheel magneto).

1. Head Light

The head light has two 6V, 25W bulbs, and a 6V, 1.5W neutral pilot light on its top. A beam direction adjusting screw is fitted on the right side of the light rim so that the horizontal direction of the beam can be adjusted (not vertically).

2. Tail Light and Stop Light

A 6V. 7W tail light and a 6V, 23W stop light are mounted. The lens of the tail light is provided with reflectors on its three sides-rear, right and left.

3. Horn

The horn is a 6V, flat type, and has a tone-volume adjusting nut on its back.

After adjustment is made, apply paint or lacquer to the nut for water proofing purposes.

4. Speedometer

A circular type speedometer is mounted on the bracket. For illumination, a 6V, 3W bulb is provided.

5. Tachometer

As in the case of the DT1, the tachometer is separated from the speedometer. The revolutions per minute (r.p.m.) of the crankshaft are carried from the primary drive gear to the tachometer drive gear in the crank case, and through the worm gear meshing with the drive gear to the tachometer cable. The light for ilumination is of 6-V, 3-W capacity.

Note: Use bulbs of the correct capacity for the head light, tail light, meter lamp, flasher light and neutral light which are directly connected to the flywheel magneto. If large capacity bulbs are used, the voltage will drop, giving a poor light. On the contrary, if smaller capacity bulbs are used, the voltage will rise, shortening the life of bulbs. Avoid the use of a 12V bulb, because shorter service life will result.

When the head light beam switch is operated to change the beam from one to anther, the head light is designed to keep its two bulbs turned on, and the beam is changed. This is to protect other light bulbs—meter lamps, tail light, etc., from burning out as a result of turning off the head light, though temporaily. If one of these light bulbs burns out while the machine is running, it will put other bulbs under an overload condition, thus shortening their service life. In this case, it is necessary to reduce the engine speed and replace the burnt bulb as quickly as possible.

Chapter VII Electrical System for AT1

VII-1 Description

The YAMAHA 125AT1 is equipped with a large-sized starter dynamo, which serves as a high-output D-C generator as well as a starter. This enables all electrical terminals to keep voltages almost constant at all times regardless of engine speeds. All electrical parts are of 12-V capacity.

| Parts | Manufacturer | Model & Type | Remarks |
|--|---|--|------------------------------|
| Starter dynamo
Spark plug | Hitachi Ltd.
NGK | GS114-01
B-8E | |
| Head light
Speedometer
Tachometer
Left handlebar switch
Right handlebar switch | I Cum Doneo | 12 V 25 W D
High beam indicator
light 12 V 1.5 W
Meter light 12 V 3 W
Meter light 12 V 3 W | Is interchangeable with DT1 |
| Main switch
Ignition coil
Horn | Asahi Denso
Hitachi Ltd.
Nikko Kinzoku | CM-11-50
MF-12 | Is interchangeable with A7 |
| Battery
Regulator
Starting switch
Fuse | Furukawa Battery
Hitachi Ltd.
Hitachi Ltd.
Osachi Mfg. | 12N7-3B1-1, 12V7AH
T107-17
A104-35
20A×2 | |
| Front stop switch
Rear stop switch | Asahi Denso
Asahi Denso | | Is interchangeable with DT1B |
| Tail/Stop light | Stanley Elec. | 12V 7W/23W | |

VII-2 Table of Component Parts

VII-3 Main Components

1. Ignition System

The main parts consist of:

Contact breaker (connected to the dynamo)

Condenser (connected to the dynamo)

Ignition coil, spark plug, high tension lead, and battery.

2. Charging and Starting Systems

Charging system: The purpose of the charging system is to charge the battery equipment (lights, horn, etc) while the machine is runing.

pw.legends

Starting system: Electric starter system is used to crank the engine.

The main parts of these two systems are:

Dynamo (yoke, armature, brushes), regulator (with cutout relay), starter button (with sarting switch), fuse and battery (power source).

3. Lighting and Signal Systems

The lighting and signal systems consist of signal lights, switch and meter lights (signal system) and illumination lights for night travel.

Signal system: Horn, stop light, and switches.

Lighting system: Headlight, taillight, and meter lights.

VII-4 Connection Diagram




Fig. VII-4-1

VII-5 Starter Dynamo

The dynamo ass'y is made up of the yoke ass'y (field coil, contact breaker, condenser, etc), the armature ass'y (armature coil, commutator) and the cam ass'y, and supplies power to the ignition and charging systems. Ignition system:

The ignition system consists of the contact breaker, condenser, and cam. The system interrupts the current flowing from the battery to the primary coil, thereby inducing a high voltage charge in the secondary coil.

a. Contact Breaker Ass'y

Incorrect ignition timing results in irregular engine speeds, thereby causing an engine knock or vibrations. It also causes loss of engine power or engine overheating, thus shortening engine life. Check the contact breaker periodicaly.

b. Condenser

The condenser stores electricity from the breaker points when the points open, and discharges the static when the points close. It prevents sparking between the points, minimizing burning by absorbing an abrupt increase in electricity when the breaker points open, and it amplifies the effect of the primary ignition coil.

Charging System:

The charging system of the starter dynamo consists of the yoke ass'y (shunt field coil and brushes) and the armature ass'y (commutator). The armature coil cuts through the magnetic lines of force of the field coil as the engine runs so that a flow of alternating current is induced. The alternating current is converted into a direct current through the commutator brushes. The direct current voltage is kept constant by the voltage regulator, and supplied to each load of the ignition, lighting and signal systems as well as to the battery.

Starting System:

In the starting system of the starter dynamo, the series coil and the armature, working as a D.C. motor, generate a great amount of torque, by which the engine is cranked.

1. Inspection and Repairs

A. Checking the Dynamo

First disconnect the wires from the terminals A (white) and F (green), then

ground the terminal F to $E\cdots$ (black), with a jumper wire. Connect the positive lead of the tester to terminal A (white), and ground the negative tester lead to the engine. Start the engine and keep it running at 1,800 rpm. If the electricity generated reads more than 10V on the tester, the gene-





- 99 -

rator is in good working condition.

Caution: Do not run the engine at more than 1,800 rpm in this test. If you run the engine at more than 1,800 rpm, a high voltage current generated will ruin the coil, lead wire, etc. (Fig. VII-5-1)

B. Checking the Yoke Ass'y

Clean the yoke with a rag to remove dust, oil, and carbon from brush wear, etc.

- Field Coil Brush Insulation Test The positive brush of the field coil is insulated from the yoke and by using the tester, you can check its insulation as shown in Fig. VII-5-2. If the insulation is bad, the circuit between the field coil or the brush holder, and the yoke is shorted. (Note: The negative brush is not insulated.)
- 2) Conductivity Test of Field Coil Check the continuity between the terminals M, A, and F. If continuity is bad, the field coil is broken. Check the visible coil connections. If the coil connections are good, then the coil is broken inside and it should be replaced because repairs are very difficult.





Fig. VII-5-3

3) Checking the Brushes

The brushes are one of the most important parts in the dynamo. Take out the brushes and check the condition of their contact surfaces. Each brush must contact the commutator with more than $\frac{3}{4}$ of its surface area.

If both brush and commutator surfaces are rough, check both the crankshaft and armature for alignment. Smooth down any burrs on the edge of the armature's tapered bore, and clean it thoroughly.

If either brush is worn past the minimum length mark, replace them both with new ones. (Fig. VII-5-4)

- Materials of the Brush Use the brush having the model No. "MH-33" on its side.
- 5) Handling the Brushes



Fig. VII-5-4

When replacing the brushes, be sure the braided lead of the positive brush does not touch the edge of the breaker plate or brush holder, and that the lead of the negative brush does not touch the positive brush spring. The friction of the braided lead against other parts as a result of vibrations may wear through the insulation and cause a short circuit.

C. Checking the Armature Ass'y

 Thoroughly clean the commutator of oil and dirt. If the commutator is rough or dulled with brush dust, polish it with fine grain sandpaper (#400-600) as shown in Fig. VII-5-5, by rotating the armature. Partial polishing will only deform the commutator and shorten brush life.



Fig. VII-5-5

If the commutator is burned, out of round, or too rough to be sandpapered, turn it on a lathe no more than 2 mm under the standard 40 mm diameter.

2) Checking the Commutator Mica Under-Cut

If the commutator is worn and if it has high mica, the mica should be undercut with a saw blade:

Sand off all burrs with sandpaper. Be sure the mica is cut away clean between segments, leaving no thin edge next to segments. (Fig. VII-5-6)

- 101 -




Fig. VII-5-6

Mica undercut inspection limits: 0.5-0.8 mm Mica undercut correction limits: 0.2 mm

3) Checking the Armature for Insulation

If there is electical leakage between the commutator and shaft, replace the whole armature. (Fig. VII-5-7)





4) If the field coil is perfectly insulated and conductivity is also good, but the dynamo will not generate electricity, the core of the armature coil might be short-circuited.

Check the armature with a growler at a special service shop.

D. Checking the Condenser

1) Insulation Tests

Hook up an electro tester (service tester) for the insulation resistance test, and attach the tester terminals to those of the condenser. If the tester needle swings once and then returns to its original position, the condenser is in good condition. Condenser leakage will hold the needle at a maximum reading. If the reading is more than $3M\Omega$, the condenser is good. Ground the condenser terminals to discharge the stored electricity. (Figs. VII-5-8 and 9)








Fig. VII-5-9

2) Capacity Tests

Set the service tester for the condenser capacity position, and connect its terminals to those of the condenser.

Condenser capacity should be no more than $0.22 \mu F \pm 10\%$. Before testing the condenser, adjust the capacity of the service tester. (Figs. VII-5-10 and 11)







Fig. VII-5-11


Note: When you make this test with the condenser mounted on the dynamo, disconnect the wires from the terminals, and insert a piece of cardboard between the breaker points.

In this test, the insulation resistance of the contact breaker can be tested at the same time. If the insulation resistance is too low, disconnect the lead wires from the condenser, and test it again.

E. Contact Breaker

- 1) Periodically inspect the breaker points and check the point gap. If the gap is incorrect, adjust it.
- 2) Periodically inspect the breaker points for any pitting.

Excessive pitting should be smoothed out with sandpaper (#400-600), and wiped off with soft cloth. (Fig. VII-5-12)



- 3) After evey 5,000 km (3,000 miles) inspect the breaker cam lubricator and grease it a little.
- 4) Oil or dust on the points impairs spark performance. The oil on the points will considerably shorten point service life. Wipe it off from time to time.

F. Adjusting Ignition Timing

1) Tools and instruments for adjusting:

Dial gauge (accuracy-1/100 mm)

Dial gauge adapter

Continuity testing lamp, YAMAHA electro tester or YAMAHA point checker

Point wrench

Slot-head screw driver


12 mm wrench

2) Adjust ignition timing

- a) Set the point gap at 0.30-0.40 mm $(0.012 \sim 0.014'')$ (Fig. VII-5-13)
- b) Remove the spark plug and screw the dial indicator holder into the plug hole. Next, insert the dial indicator into the holder. Bring the piston up to T.D.C. and set the zero on the dial face to line up exactly with the dial indicator needle. (Fig. VII-5-14)

Remove the lead wire from terminal I. Connect the positive (+) tester lead to the terminal I, and ground the tester's negative lead to the frame. (Fig. VII-5-15)

f) Turn the crankshaft back well past 1.8 mm, to eliminate play in the gears,




and then bring the piston up to exactly 1.8 mm B.T.D.C. (Fig. VII-5-16).

Fig. VII-5-15



d) Insert a matchwood into the governor, and wedge it fully opened. Then loosen the breaker plate holding screws, and turn the braker plate. When the points just start to open (the testing lamp lights up), tighten the holding screws. (Do not fully loosen the breaker plate holding screw, because the breaker plate tends to shift its position). Turning the breaker plate in the engine rotation direction causes ignition timing to delay, and turning it in the opposite direction advances ignition timing. (Figs. VII-5-17 and 18)



8) Dynamo Adjustment Standards

| Part | Item | Maintenance | Inspection |
|------------|----------------------------|---|--|
| Field | Resistance Shunt
Series | 4.8Ω @20°C (68°F)
0.0268Ω @20°C (68°F) | When voltage is irregular |
| Brushes | Material | MH-33 | First 6,000 km (4,000 mi.)
Every 4,000 km thereafter
(2,500 mi.) |
| | Number | 4 | |
| | Width× thickness× length | 9×4.5×20.5 mm | |
| | Minimum length | 9 mm | |
| | Spring capacity | 400±10%-560±10% | |
| | | (initial use) | |
| Commutator | Diameter | 38.5 ∮mm | |
| | Minimum diameter | 36.5 ∮mm | |
| | Mica undercut | 0.5-0.8 mm | |
| | Minimum mica undercut | 0.2 mm | |
| | Difference between max. | 0.03 mm | |
| | and min. diameter | | |
| Breaker | Point gap | 0.30-0.40 mm | Every 3,000 km (2,000 mi.) |
| | Point pressure | 500~700 g | (High rpm irregular) |
| | Ignition timing | BTDC 1.8 mm | (Ignition irregular) |
| | Automatic spark advance | Starting 1,350±150 rpm | |
| | | Final 1,600±100 rpm | |
| | | Advance 12±2° | |
| Others | Dynamo dia. (outer) | 134 ¢mm | |
| | Dynamo dia. (inner) | 130 ømm | |
| | No. of poles | 8 | |
| | Air gap | 0.35 mm | |
| | Armature taper | 20 \$\not \times 1/5 | |
| | Cut-in rpm | 2,000 rpm | |
| Capacity | Rated output rpm | 14-V, 4.5A/1,950 rpm | |

VII-6 Regulator (Voltage Regulator)

The dynamo alone can not provide stable electric current because fluctuating engine rpm affects the voltage. The regulator (also called a voltage relay) stabilizes the voltage generated by breaking the field coil circuit when the voltage exceeds a pre-set level.

A cutout relay (also called a charging relay) is built into the regulator. It allows stable electric current from the dynamo to charge the battery. However, when the engine stops, or when its speed is so low that the dynamo output is lower than that of the battery voltage, it breaks the circuit to the battery so the battery will not drain. The starting switch is provided to direct a flow of current to the starter dynamo when the engine is started.

1. Inspection and Adjustment

If the regulator can no longer control the voltage, the battery will be drained or over-charged, and all electrical parts may be burned out. So use a good tester when inspecting or adjusting the regulator. (It is advised that you learn how to adjust the regulator at training courses because it is very difficult.)

A. No-Load Voltage

- 1) Inspection
 - O Disconnect the lead wire (red) of the regulator and connect the positive tester lead to the lead wire (red). Then ground the negative tester lead.
- O Start the engine and keep it running at 2,500 rpm. Your regulator is correct if the tester reads 15.8-16.5 V. (Fig. VII-6-1)





Fig. VII-6-1

2) Adjustment

If the measured voltage is more or less than specified, adjust it by tightening or loosening the adjusting screw on the voltage relay side.



B. Cut-in voltage of the Cutout Relay

1) Inspection

O Disconnect the lead from the dynamo A terminal, connect the tester positive lead to the A terminal, then ground the negative lead to the engine.


(Fig. VII-6-3)

O Start the engine, and increase engine speeds slowly. The cut-

out relay is correctly set if its breaker points close at 12.5-13.5 V. (approx. 1,800 rpm)

2) Adjustment

If the breaker points will not close at the specified voltage, adjust the cutout relay by changing its spring tension. (Fig. VII-6-4)



In actual practice, there will rarely be need to adjust the cutout relay. If the point surfaces of the voltage and cutout relays are worn or pit

If the point surfaces of the voltage and cutout relays are worn or pitted, polish them with fine sandpaper (#400-600) before making any adjustment.



Fig. VII-6-3

| 3) Regulator | Maintenance | Standards |
|--------------|-------------|-----------|
|--------------|-------------|-----------|

| | Item | Maintenance standards | Inspection |
|-------------------|--------------------|---|-----------------|
| Voltage regulator | No load voltage | 15.8-16.5V/2,500 rpm | When voltage is |
| | adjustment value | | irregular |
| Voltage relay | Voltage coil | 11.8 Ω/20°C (68°F) | |
| | resistance value | | |
| | Compensation value | 10Ω/20°C(68°F) | |
| | | | |
| | Core gap | 0.4-0.7 mm | |
| | Point gap | 0.4-0.5 mm | |
| Cutout relay | Cut-in voltage | 13±0.5V | |
| | Reversing current | 5 A or less | |
| | Voltage coil | $11.2 \Omega/20^{\circ} C (68^{\circ} F)$ | |
| | resistance value | , | |
| | Core gap | 0.8-1.0 mm | |
| | Point gap | 0.6~0.8 mm | |

VII-7 Ignition Coil

The ignition coil is a kind of transformer, with approximately 50 times the number of windings in the secondary coil as in the primary. If the electric current supplied to the primary coil (from the battery) is interrupted by a contact breaker, the primary coil will create a 150 - 300 V current by selfinduction. This current is boosted to 12,000-14,000 V by mutual induction in the larger number of secondary coil windings, thereby making a spark jump the plug electrodes,





Fig. VII-7-1

www.leyends>yumahu>enduros.com

1. Inspection

If no spark, or a rather weak spark jumps the plug gap, inspect the ignition coil as well as the contact breaker.

- Blue spark Primary coil a. When you test the coil alone, 8 Œ use a 12-V battery as power Orange Brown source. Secondary coil () A spark of 7 mm or more ΘØ means the coil is in good condition. Ignition coil Fig. VII-7-2
- b. Test with Coil Installed (practical test)



- ODisconnect the lead attached to the ignition dynamo terminal I and connect the negative primary and negative secondary leads of the tester to it.
- ODetach the high tension lead from the plug, attach an adapter (copper or iron wire) to the plug lead cap, and connect this adapter lead to the positive secondary lead of the tester.
- OConnect the positive primay lead of the tester to the brown lead terminal of the horn.
- OUse a 12-V battery as power source for the tester.

Olf the tester shows a spark of 7 mm or more, the coil is in good condition.

Chapter VIII Conversion of the Yamaha AT1 for racing*(AT1M has these parts)

The Yamaha 125 AT1 is easily converted into a high-performance motocrosser by installng GYT kit parts.

*It is suggested that when you desire to make this conversion, you enlist the services of your local Yamaha dealer.

VIII-1 Engine Tune-up

The engine can be tuned up by simply replacing standard parts with tuned parts. List of GYT kit Parts

| No. | Part No. | Part Name | Q'ty | Remarks |
|-----|--------------|-----------------------|------|---|
| 1 | 248-11111-70 | Head, cylinder | * 1 | |
| 2 | 248-11311-70 | Body, cylinder | 1 | |
| 3 | 248-11631-70 | Piston | 1 | One ring |
| 4 | 94700-00035 | Plug, spark | 1 | NGK B-9E |
| 5 | 248-11611-70 | Ring, piston-top | 1 | |
| 6 | 248-14101-70 | Carburetor assembly | 1 | VM26SH |
| 7 | 97201-08040 | Bolt | 1 | |
| 8 | 248-13511-70 | Joint | 1 | |
| 9 | 248-13556-70 | Gasket | 1 | |
| 10 | 161-15426-00 | Cover, oil pump | 1 | Required only when travel-
ling with oil pump removed. |
| 11 | 248-14610-70 | Exhaust pipe assembly | 1 | |
| 12 | 174-17461-30 | Sprocket, drive | 1 | 13T (13T is standard) |
| 13 | 174-17461-40 | Sprocket, drive | 1 | 14T |
| 14 | 174-17461-50 | Sprocket, drive | 1 | 15T |
| 15 | 174-17461-60 | Sprocket, drive | 1 | 16 T |
| 16 | 214-17819-10 | Cap, housing | 1 | Remove tachometer, and install cap instead. |
| 17 | 248-81300-00 | Magneto | 1 | |
| 28 | 248-11412-60 | Crankshaft, left | 1 | Same as left
Because of the magneto
being used. |

VIII-2 Modification of the Chassis

Modification of the chassis just requires the removal of the chassis components unnecessary for motocross.

O Replace both front and rear tires with those of the motocross specification.

OChoose the most suitable sprocket wheel for motocross.

Several types of sprocket wheels, varying in the number of teeth, are available at your Yamaha dealer's shop.

- O Remove all electrical components together with the wire harness, except for the magneto and ignition coil. As an option, the magneto of the racing specification available. (Refer to the List of Motocross Tuning Parts.)
- O Connect the black lead of the magneto to the same color lead of the ignition coil. It is advisable to use the following optional parts to make the AT1 the fullequipped motocrosser.

| No. | Part No. | Part Name | Q'ty | Remarks |
|-----|--------------|----------------------|--------------------|---|
| 1 | 248-25443-10 | Gear, sprocket wheel | 1 | 43T |
| 2 | 248-25445-10 | Gear, sprocket wheel | 1 | 45T |
| 3 | 248-25447-10 | Gear, sprocket wheel | 1 | 47T (47T is standard) |
| 4 | 248-25449-10 | Gear, sprocket wheel | 1 | 49T |
| 5 | 94418-18045 | Rim | Rim 1 1.85E | |
| 6 | 214-25394-00 | Spacer, bead | 1 | For 1.85B |
| 7 | 94135-18000 | Tire | 1 For rear-3.50-18 | |
| 8 | 94235-18022 | Tube | 1 | For rear-3.50-18 |
| 9 | 94335-18018 | Band, rim | 1 | For 3.50-18 |
| 10 | 94127-21071 | Tire | 1 | For front-2.75-21 |
| 11 | 94227-21031 | Tube | 1 | For front-2.75-21 |
| 12 | 94327-21024 | Band, rim | 1 | For front-2.75-21 |
| 13 | 94416-21044 | Rim | 1 | 1.60A×21 |
| 14 | 248-25196-10 | Spoke, inner | 18 | For 1.60A×21 |
| 15 | 248-25197-10 | Spoke, outer | 18 | For 1.60A×21 |
| 16 | 214-25194-00 | Spacer, bead | 1 | For 1.60A |
| 17 | 152-25139-00 | Blind plug | | Remove speedometer and
install blind plug. |

The AT1M is provided with these tuning parts. (Front tire size is 3.25-18)

VIII-3 Service Data (Tuning parts specifications)

OPiston clearance......0.040-0.050 mm

OPiston ring end gap0.5 mm or less

(when piston is fitted in cylinder)

O Spark plug Standard B-9E

OIgnition timing2.0 mm B.T.D.C.

OCarburetor setting M. J. (Main jet) #240

J.N. (Jet needle) 4D3-3 stages

N.J. (Needle jet) 0-2

C.A. (Throttle valve 1.5 cut-away)

P.J. (Pilot jet) #30

A. S. (Air screw) turns out 1¹/₂ turns

OFuel mixing ratioAutolube in use: 30:1 Oil in GAS.

Autolube Disconnected: 15:1 Oil in GAS.

* These tuning parts, optional parts and service data may be subject to change without advance notice.

When desiring any of these parts, consult your Yamaha dealer as to Their available.

VIII-4 Change in Specifications

Participants in racing must change specifications of the machine depending on conditions of the racing course, road surface, soil, length of straight aways, angles of curves, number of curves, slopes, weather, temperatures, and skill of the rider. These factors and conditions must be determined by the rider himself after trial running over the whole race course.

Main Points to be Moditied

OCarburetor Setting

In addition to the specified M.J., the rider should carry with him spare M.J.s whose size numbers are larger and smaller than specified by 10, respectively.

O Secondary Reduction Ratio

Consideration should be given to a combination of the drive sprocket and sprocket wheel so that gear shifting to 3rd and 4th is easy.

O Plug

Change the plug by judging discoloration of the plug. Choose the most suitable

one from B-8EN, B-9EN and B-10EN.

OTire Pressure

Adjust the tire pressure, according to road conditions and the rider's choice. OFront Fork

Adjust the front fork by adjusting the quantity of oil. (The oil amount is in the range of 145 to 160 cc.)

Note: The 250 DT1 front fork can be used for the AT1 without modifying it.

ORear Cushions

Adjust the spring depending on the rider's choice. It is possible to use the DT1 rear cushions for the AT1 without modifying them.

OHandlebar

Loosen the handle lever holder before racing. It will protect the rider'r hands or fingers from getting injured, in case of an accidental crash during the race. (The lever can easily turn when the machine turns over.)

VIII-5 Miscellaneous Notes

Racing requires the severest operation of the machine as well as high performance and extra durability.

Accordingly, thorough inspection and service of the machine before racing are very important. In particular, the engine will be operated at high speeds for many consecutive hours. Hence, even a minor defect may result in engine troubles. Be sure to check and service the machine with special care prior to racing.

The newly tuned up engine must be handled in the same manner as a brand new machine, so it requires a certain period of braking-in.

O The racer should devote the maximum possible time to inspection and service of the machine prior to racing. "Thorough inspection and service are the first step to victory."

Note:

1) These parts may be subject to change in specifications (part numbers, setting values, etc.). When using them, consult your Yamaha dealer.

CONVERSION TABLES

12

and the second s

vww.togundo-gamaha>enduro:

LENGTHS

| Multiply
Millimeters (mm)
Inches (in.)
Centimeters (cm.)
Inches (in.) | By To ObtainMultiply0.03937 InchesKilometers (km.)25.4 MillimetersMiles (mi.).3937 InchesMeters (m.)2.54 CentimetersFeet (ft.) | | By To Obtain
.6214 Miles
1.609 Kilometers
3.281 Feet
.3048 Meters | | | |
|---|--|--------------------------|---|--|--|--|
| WEIGHTS | | | | | | |
| Kilograms (kg.) | 2.205 Pounds | Grams (g.) | .03527 Ounces | | | |
| Pounds (1bs.) .4536 Kilograms | | Ounces (oz.) | 28.35 Grams | | | |
| VOLUMES | | | | | | |
| Cubic centimeters (c.c.) | .061 Cubic inches | Imperial gallons | 277.274 cu.in. | | | |
| Cubic inches (cu.in) | 16.387 c.c. | Liters (l.) | 1.057 Quarts | | | |
| Liters (1.) | .264 Gallons | Quarts (qt.) | .946 Liters | | | |
| Gallons (gal.) | 3.785 Liters | Cubic centimeters (c.c.) | .0339 Fuid ounces | | | |
| U.S. gallons | 1.2 Imperial gals. | Fluid ounces (fl. oz.) | 29.57 c.c. | | | |
| Imperial gallons | 4.537 Liters | | | | | |

OTHERS

| Metric horsepower (ps.) | 1.014 bhp. | Foot-pounds (ft-1b) .1383 | kg-m |
|-------------------------|-------------|---------------------------------|------|
| Brake horsepower (bhp.) | .9859 ps. | Kilometers per liter(km/1)2.352 | mpg |
| Kilogram-meter (kg-m) | 7.235 ft-lb | Miles per gallon (mpg) .4252 | km/l |

GAS (FUEL) TO OIL RATIO CHART

| Gas/Oil Ratio | 12:1 | 16:1 | 20:1 | 24:1 | 28:1 | 32:1 | 36:1 | 40:1 |
|--------------------------|------|------|------|------|------|------|------|------|
| Oil (qt.) per 1 Gal. Gas | 0.33 | 0.25 | 0.2 | 0.17 | 0.14 | 0.13 | 0.11 | 0.1 |
| Oil (oz.) per 1 Gal. Gas | 10.7 | 8.0 | 6.4 | 5.3 | 4.6 | 4.0 | 3.6 | 3.2 |
| Oil (qt.) per 5 Gal. Gas | 1.66 | 1.25 | 1.0 | 0.84 | 0.72 | 0.63 | 0.55 | 0.5 |
| Oil (oz.) per 5 Gal. Gas | 53.5 | 40.0 | 32.0 | 26.6 | 22.8 | 20.0 | 17.8 | 16.0 |
| | | | | | | | | |

(U.S. Gallons)

- 115 -

MEMO

| Dot she can be a set of the set o |
|--|
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |
| |


- 116 -


MEMO

| | •• |
|------|-----|
| | ••• |
| | |
| | |
| | - |
| 2000 | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

117 -

YAMAHA AT1 WIRING DIAGRAM





www.legends-yamaha-enduros.com

